



Parts List					Qty	Comment	Footnote
Ref	Class	Part	Description				
1		62285	BRACKET, MOUNTING (REAR)	2			
2	10	47462	SCREW, MOUNTING BRACKET T	4			
3	13	32993	LOCKWASHER, MOUNTING BRA	4			
4	10	47654	SCREW, CLAMPING-MOUNTING	2			
5	13	32993	LOCKWASHER, CLAMPING SCRE	2			
6	54	47528	CLAMP, ADJUSTING TRUNNION	4			
7	11	29553	NUT, SCREW CLAMPING	2			
8		71128	BRACKET, MOUNTING - ENGINE	2			
9	10	37612	SCREW, MOUNTING BRACKET T	4			
10	13	35048	LOCKWASHER, MOUNTING BRA	4			
11	10	37269	SCREW, CLAMPING - MOUNTING	2			
12	13	32993	LOCKWASHER, SCREW CLAMPIN	2			
13	11	29553	NUT, SCREW CLAMPING	2			
14		66166	TRUNNION, ADJUSTING - MOUN	4			
15	13	68102	LOCKWASHER, MOUNTING BRA	4			
16		66284	BASE, ENGINE MOUNT	4			
17	11	20739	NUT, JAM - ENGINE MOUNT	8			
18	14	66658	TAB WASHER, ENGINE MOUNT I	2			
--	16	46857	STUD, CARBURETOR MOUNTING	2			
--	10	28701	SCREW, CARBURETOR MOUNTING	2			
--	13	39107	LOCKWASHER, CARBURETOR M	2			
--		49457	GAUGE, OIL LEVEL (DIPSTICK)	1			
--		60212A	EXHAUST, ELBOW RISER	2			
--	16	49545	STUD, EXHAUST ELBOW TO	8			
--	22	32802	PLUG, EXHAUST ELBOW TO	2			
--	22	36305	ELBOW, EXHAUST RISER	2			
--	16	60607	STUD, MANIFOLD TO RISER (2	1			
--	11	49838	NUT, RISER TO EXHAUST ELBO	8			
--	13	37459	LOCKWASHER, RISER TO EXHA	8			
--	27	52076	GASKET, ELBOW TO RISER	6			
--		73813A	END CAP, REAR	2			
--	27	73814	GASKET, END CAP TO EXHAUST	2			
--	10	25299	SCREW, END CAP ATTACHING (8			

V-DRIVE

E-3