



| Parts List | | | | | | |
|------------|-------|--------|-----------------------------|-----|--------------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| 1 | | 70981A | EXHAUST BELLOWS | 2 | | |
| 2 | 54 | 33683 | CLAMP (SMALL) | 12 | | |
| 3 | 54 | 31765 | CLAMP (LARGE) | 4 | | |
| 4 | | 94443A | EXHAUST ELBOW - CASTING #9 | 2 | EARLY MODELS | |
| 4A | | 94443A | EXHAUST ELBOW (STDB) - CAST | 1 | LATER MODELS | |
| 4A | | 94444A | EXHAUST ELBOW (PORT) - CAST | 1 | LATER MODELS | |
| 5 | 32 | 90949 | EXHAUST TUBE | 2 | | |
| 6 | | 99370A | WATER SHUTTER | 2 | | |
| 7 | | 94981A | EXHAUST PIPE (USE WITH REF. | 1 | | |
| 7A | | 99877A | EXHAUST PIPE (USE WITH REF. | 1 | | |
| 8 | 10 | 58640 | SCREW, EXHAUST PIPE TO STE | 4 | | |
| 9 | 13 | 41471 | LOCKWASHER, EXHAUST PIPE | 4 | | |