



19881

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		97401A 8	FUEL PUMP	1		
2	27	34213	GASKET, FUEL PUMP TO CYLINE	1		2
3	10	34354	SCREW, (.375-16 x 1.50), FUEL PL	2		
4	13	35048	LOCKWASHER, (.375), FUEL PUM	2		
5		35373	MOUNTING PLATE, FUEL PUMP	1		
6	27	34898	GASKET, FUEL PUMP MOUNTIN(1		2
7	10	35366	SCREW, (.250-20 x .563), FUEL PL	2		
8		35377	ROD, PUSH - FUEL PUMP	1		
9		89876A 3	BASE ASSEMBLY, Fuel Filter/Wate	1		
10	22	36382	FITTING, (.250-18 Brass), PIPE - FI	3		
11		88641	INSULATOR, MOUNTING - FUEL	1		
12	10	26065	SCREW, (.312-24 x 1.00), FUEL FII	2		
13	11	35814	NUT, (.312-24), FUEL FILTER SCF	2		
14	35	60494	FUEL FILTER	1		
15	22	33821	CONNECTOR, FUEL LINE TO FUE	3		
16	32	97326	FUEL LINE, FILTER TO FUEL PUM	1		
17	32	96081A 1	FUEL LINE, FUEL PUMP TO CARB	1		
18	32	73815 63	HOSE, (.34.00 Inches Bulk), PLAST	1		
-	27	75611A88	ENGINE GASKET SET	1		