



| Parts List |       |          |                             |     |                          |          |
|------------|-------|----------|-----------------------------|-----|--------------------------|----------|
| Ref        | Class | Part     | Description                 | Qty | Comment                  | Footnote |
| -          | 1623  | 8951A 2  | GEAR HOUSING                | 1   |                          |          |
| 1          | 1623  | 5356A 4  | GEAR HOUSING                | 1   |                          |          |
| 53         | 18    | 89212    | COTTER PIN, CLUTCH ACTUAT   | 1   |                          |          |
| 54         |       | N.S.S.   | SLEEVE, ADJUSTING - REPLAC  | 1   |                          |          |
| 55         |       | N.S.S.   | RETAINER, SPRING - REPLACE  | 1   |                          |          |
| 56         |       | N.S.S.   | WASHER - REPLACED BY 1975   | 2   |                          |          |
| 57         |       | N.S.S.   | SPRING - REPLACED BY 1975   | 1   |                          |          |
| 58         |       | N.S.S.   | SPOOL - REPLACED BY 1975    | 1   |                          |          |
| 59         |       | N.S.S.   | SHAFT - REPLACED BY 1975    | 1   |                          |          |
| 60         |       | 76865    | SHIFT CRANK                 | 1   |                          |          |
| 61         | 15    | 47397A 1 | SHIM                        | AR  |                          |          |
| 62         | 43    | 92158A 1 | FORWARD GEAR                | 1   |                          |          |
| 63         | 31    | 30895    | ROLLER BEARING, FORWARD     | 1   |                          |          |
| 64         | 31    | 35928A 1 | TAPERED ROLLER BEARING A    | 1   |                          |          |
| 65         | 52    | 66063    | CLUTCH                      | 1   |                          |          |
| 66         | 17    | 30632    | CROSS PIN                   | 1   |                          |          |
| 67         | 24    | 30893    | SPRING, RETAINER - CROSS P  | 1   |                          |          |
| 68         | 44    | 66060    | PROPELLER SHAFT             | 1   |                          |          |
| 69         | 43    | 61026    | REVERSE GEAR                | 1   |                          |          |
| 70         |       | 35915    | THRUST RING, BEARING CARF   | 1   |                          |          |
| 71         | 30    | 17927    | BALL BEARING, REVERSE GE    | 1   |                          |          |
| 72         | 15    | 31535A 1 | SHIM                        | AR  |                          |          |
| 73         | 25    | 31534    | O-RING, BEARING CARRIER     | 1   |                          |          |
| 74         |       | 73020A14 | BEARING CARRIER ASSEMBLY    | 1   |                          |          |
| 75         | 31    | 30956    | ROLLER BEARING              | 1   |                          |          |
| 76         | 26    | 76868    | OIL SEAL                    | 2   |                          |          |
| 77         | 28    | 30281    | KEY                         | 1   |                          |          |
| 78         | 14    | 79447    | TAB WASHER, GEAR HOUSING    | 1   |                          |          |
| 79         |       | 79448    | COVER, GEAR HOUSING         | 1   |                          |          |
| 80         |       | 56292A 2 | THRUST HUB AND WASHER AS:   | 1   |                          |          |
| 81         | 12    | 35365    | WASHER, CUPPED              | 1   |                          |          |
| 82         | 12    | 31211A 2 | WASHER, SPLINED - PROPELLER | 1   |                          |          |
| 83         | 14    | 31210    | TAB WASHER, PROPELLER NUT   | 1   |                          |          |
| 84         | 11    | 52707A 1 | PROPELLER NUT               | 1   |                          |          |
| 85         |       | 34127A 1 | TRIM TAB ASSEMBLY           | 1   | SERIAL 00000000-04428019 |          |
| 85         |       | 31640A 1 | TRIM TAB ASSEMBLY           | 1   | SERIAL 04428020-09999999 |          |
| 86         | 10    | 32470    | SCREW, TRIM TAB TO GEAR HO  | 1   |                          |          |
| 87         | 10    | 30206    | SCREW, GEAR HOUSING TO DR   | 1   |                          |          |
| 88         | 11    | 34933    | NUT, DRIVE SHAFT HOUSING TC | 2   |                          |          |