



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		64787	OIL PUMP ASSEMBLY	1		
2	27	64789	GASKET, OIL PUMP	1		3
3	27	56859	GASKET, OIL PUMP SCREEN	1		3
4		64788	SCREEN, OIL PUMP (STERN DRIV	1		
4	32	62131A	OIL PICKUP ASSEMBLY (INBOAR	1		
5	10	56858	SCREW, SCREEN TO OIL PUMP	2		
6	24	64791	SPRING, OIL PUMP RELIEF VALV	1		
7		64792	PLUNGER, OIL PUMP RELIEF VA	1		
8	19	65117	PLATE, OIL PUMP	1		
10	10	56133	SCREW, PLATE TO OIL PUMP (5,	4		
11	13	26992	LOCKWASHER, PLATE SCREW	4		
12		64786	SHAFT ASSEMBLY, OIL PUMP	1		
13	53	56860	RING, RETAINING - OIL PUMP	1		
14		64785	ROTOR AND SHAFT, OIL PUMP	1		
15	10	56176	SCREW, OIL PUMP TO CYLINDER	2		
16	13	56177	LOCKWASHER, OIL PUMP SCREW	2		
17		72566	OIL PAN (STERN DRIVE)	1		
17		59529	OIL PAN (INBOARD)	1		
18	27	65114A	GASKET SET, OIL PAN	1	SERIAL 00000000-04465029	
18	27	75483	GASKET SET, OIL PAN	1	SERIAL 04465030-09999999	
19	22	60720	PLUG, PIPE - OIL PAN DRAIN (ST	1		
19	22	36373	PLUG, PIPE - OIL PAN DRAIN (IN	1		
20	27	60721	GASKET, OIL DRAIN PLUG	1		
21	10	60710	SCREW, OIL PAN TO CYL. BLOCK	4		
22	10	60708	SCREW, OIL PAN TO CYL. BLOCK	18		
21	10	55714	SCREW, OIL PAN TO CYL. BLOCK	4		
22	10	55715	SCREW, OIL PAN TO CYL. BLOCK	8		
23	13	26993	LOCKWASHER, OIL PAN SCREW	8		
23	13	26992	LOCKWASHER, OIL PAN SCREW	1		
24	22	47625	ELBOW, OIL LEVEL GAUGE TUBE	1		
25	11	47626	NUT, OIL LEVEL GARGE TUBE IP	1		
26		62965	TUBE, OIL LEVEL GAUGE (STERN	1		
26		47492	TUBE, OIL LEVEL GAUGE INBOAR	1		
27		70717	BRACKET, OIL LEVEL GAUGE TU	1		
28	54	28938	CLIP, OIL LEVEL GAUGE TUBE IP	1		
29	10	21548	SCREW, OIL GAUGE TUBE CLIP	1		
30	13	26992	LOCKWASHER, OIL LEVEL GAUC	1		
31	11	20088	NUT, OIL LEVEL GAUGE TUBE CI	1		
32		63179	GAUGE, OIL LEVEL (DIPSTICK)-S	1		
32		62311	GAUGE, OIL LEVEL (DIPSTICK)-H	1		