



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		63588A	1 THERMOSTAT HOUSING ASSEM	1		
2	23	54476	SLEEVE, THERMOSTAT HOUSI	1		
3	10	54523	SCREW, HOUSING TO INTAKE M	1		
3	10	35386	SCREW, HOUSING TO INTAKE M	1		
4	12	20084	WASHER, THERMOSTAT HOUSI	2		
5	27	54506	GASKET, THERMOSTAT HOUSIN	1		4
6		59137	THERMOSTAT	1		
7		59498	COVER, THERMOSTAT(INBOARC	1		
7		62898	COVER, THERMOSTAT(STERN C	1		
8	27	60208	GASKET, THERMOSTAT COVER	1		4
9	10	24234	SCREW, THERMOSTAT COVER	3		
10	13	39107	LOCKWASHER, THERMOSTAT C	3		
11	32	54570	HOSE, THERMOSTAT HOUSING	1		
12	54	32781	CLAMP, HOSE TO THERMOSTAT	2		
13	32	64815	HOSE, THERMOSTAT HOUSING	1		
13	32	63576A	1 HOSE ASSEMBLY, THERMOSTA	1		
14	54	64488	CLAMP, HOSE ATTACHING STEF	1		
14	54	64489	CLAMP, HOSE ATTACHING STEF	2		
15	54	32780	CLAMP, HOSE ATTACHING STEF	2		
16		70341	ELBOW, EXHAUST STERN DRIVE	2	SERIAL 00000000-04474705	
16		73739	ELBOW, EXHAUST STERN DRIVE	2	SERIAL 04474706-09999999	
17	10	60992	SCREW, EXHAUST ELBOW TO E	6		
18	13	35048	LOCKWASHER, EXHAUST ELBO\	6		
19		53821	BELLOWS, EXHAUST ELBOWSTI	2	SERIAL 00000000-04474705	
19		70981	BELLOWS, EXHAUST ELBOWSTI	2	SERIAL 04474706-09999999	
20	54	33683	CLAMP, BELLOW TO EXHAUST E	4		
20	54	31765	CLAMP, LARGE STERN DRIVE	4		
21	25	35029	"O" RING, EXHAUST ELBOW TO	2		
22		60930	SHUTTER, WATER EXHAUST SE	2		
23		60931	RETAINER, WATER SHUTTER S	2		
24		59825	SEPARATOR, EXHAUST STERN	1		
25	10	60835	SCREW, EXHAUST SEPARATOR	1		
26	10	37612	SCREW, EXHAUST SEPARATOR	4		
27	13	35048	LOCKWASHER, EXHAUST SEPA	5		