



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	749	5791	PISTON AND PISTON PIN ASSY	8	SERIAL 00000000-04500860	
1	749	5795	PISTON AND PISTON PIN ASSY	AR	SERIAL 00000000-04500860	
1	749	5796	PISTON AND PISTON PIN ASSY	AR	SERIAL 00000000-04500860	
1	749	6561	PISTON AND PISTON PIN ASSY	8	SERIAL 04500861-09999999	
1	749	6562	PISTON AND PISTON PIN ASSY	AR	SERIAL 04500861-09999999	
1	479	6563	PISTON AND PISTON PIN ASSY	AR	SERIAL 04500861-09999999	
2	39	56114	RING ASSEMBLY, PISTON (STAN	4	EACH PART NUMBER INCLUDE	
2	39	56115	RING ASSEMBLY, PISTON (.020 C	AR	EACH PART NUMBER INCLUDE	
3	623	5914	CONNECTING ROD ASSEMBLY	8		
4	10	64770	BOLT, CONNECTING ROD	16		
5	11	64769	NUT, CONNECTING ROD BOLT	16		
6	23	64764	BEARING UNIT, CONNECTING RI	8		
6	23	64765	BEARING UNIT, CONNECTING RI	AR		
6	23	64766	BEARING UNIT, CONNECTING RI	AR		
6	23	64767	BEARING UNIT, CONNECTING RI	AR		
6	23	64768	BEARING UNIT, CONNECTING RI	AR		
7	446	5105	CRANKSHAFT (LEFT HAND CRAF	1	SERIAL 00000000-04500860	
7	446	5106	CRANKSHAFT (RIGHT HAND CRA	1	SERIAL 00000000-04500860	
7	446	6564	CRANKSHAFT (LEFT HAND CRAF	1	SERIAL 04500861-09999999	
8	238	4428	FLYWHEEL ASSEMBLY - 157 TEE	1	SERIAL 04500861-09999999	
8	238	4055	FLYWHEEL ASSEMBLY - 164 TEE	1		
9	10	60706	BOLT, FLYWHEEL TO CRANKSH	6		
10		47608	DRIVE PLATE, FLYWHEEL-INBO.	1		
11	10	56889	SCREW, DRIVE PLATE TO FLYW	6		
12	13	26993	LOCKWASHER, DRIVE PLATE SC	6		
13		59826A	ENGINE COUPLING ASSEMBLY E	1		
14	16	60993	STUD, ENGINE COUPLING ATTA	1		
15	12	32648	WASHER, ENGINE COUPLING AT	6		
16	11	56407	NUT, ENGINE COUPLING ATTAC	6		
17	26	64796	OIL SEAL, CRANDKSHAFT REAR	1		
17	26	64797	OIL SEAL, CRANDKSHAFT REAR	1		
18	23	64774	BEARING, CRANKSHAFT MAIN (E	8		
18	23	64775	BEARING, CRANKSHAFT MAIN (J	AR		
18	23	64776	BEARING, CRANKSHAFT MAIN (J	AR		
18	23	64777	BEARING, CRANKSHAFT MAIN (J	AR		
19	23	64778	BEARING, CRANKSHAFT MAIN -I	1		
19	23	64779	BEARING, CRANKSHAFT MAIN -I	AR		
19	23	64780	BEARING, CRANKSHAFT MAIN -I	AR		
19	23	64781	BEARING, CRANKSHAFT MAIN -I	AR		
20	28	64771	KEY, TIMING SPROCKET TO CRA	1		
20	28	76619	KEY, TIMING SPROCKET TO CRA	1	SERIAL 04500861-09999999	