



				Parts List		
Ref	Class	Part	Description	Qty	Comment	Footnote
1	392	6330	DISTRIBUTOR (L/H CRANKSHAF	1		
1	392	6335	DISTRIBUTOR (R/H CRANKSHAF	1		
2	392	6318	CAP, DISTRIBUTOR	1		1
3	392	6329	GASKET, DISTRIBUTOR CAP	1		1
2	392	9766	CAP, DISTRIBUTOR	1		8
4	392	6326	ROTOR	1		1
4	392	9767	ROTOR	1		8
5	392	6323	PLATE	1		
6	392	6325	BREAKER	1		
7	392	6324	CONDENSER	1		
8	392	6319	SPRING, DISTRIBUTOR CAP	1		1
9	392	6331	BEARING, DISTRIBUTOR	1		
10	392	6334	SHAFT	1		1
10	392	9768	SHAFT	1		8
11	392	6332	GEAR AND COLLAR(L/H CRANI	1		
11	392	6336	GEAR AND COLLAR(R/H CRAN	1		
12	392	6333	O-RING(1- 1/2"O.D.)	1		
13	392	6322	PRIMARY LEAD	1		1
13	392	9088	PRIMARY LEAD	1		8
15		58258	DISTRIBUTOR CLAMP	1		
16	10	58259	SCREW, DISTRIBUTOR CLAMP	1		
17	13	58260	LOCKWASHER, CLAMP SCREW	1		
18	84	75780	LEAD ASSEMBLY, DISTRIBUTOR	1		
19		32193	IGNITION COIL	1		
20		65970	BRACKET, IGNITION COIL	1		
21	10	66652	SCREW, BRACKET	1		
22	13	34058	LOCKWASHER, BRACKET SCREW	1		
23	12	30164	WASHER, IGNITION COIL TERMI	2		
24	13	26996	LOCKWASHER, IGNITION COIL T	2		
25	11	68219	NUT, IGNITION COIL TERMINAL	2		
26	10	98556	SCREW, IGNITION COIL (1-3/4")	1		
27	12	20553	WASHER, IGNITION COIL SCREW	1		
28	23	60339	SPACER, IGNITION COIL SCREW	1		
26	10	26632	SCREW,IGNITION COIL (1-1/4")	1		
27	12	20553	WASHER, INGITION COIL SCREW	1		
28	23	90523	SPACER, IGNITION COIL SCREW	1		
29	84	43376A	9 LEAD ASSEMBLY, HIGH TENSIO	1		
30	85	63709A	1 PROTECTOR, SPARK PLUG	8		
31	33	61783	SPARK PLUG(18MM)	8		
31	33	76154	SPARK PLUG (14MM)	8		
32		64676	RETAINER (2 W/RES)	2		