


**MERCURY MARINE**



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		64026A	DISTRIBUTOR ASSEMBLY, COM	1	
1		64026A	DISTRIBUTOR ASSEMBLY, COM	1	
2	393	4988	CAP, DISTRIBUTOR	1	
	37	54675	DECAL, DISTRIBUTOR CAP	1	
3		65864	ROTOR	1	
4	10	36046	SCREW, BREAKER AND CONDE	3	
5	81	64851	CONDENSER	1	
6		64850	BREAKER ASSEMBLY	1	
7	84	64846	LEAD ASSEMBLY, PRIMARY TE	1	
8	54	65783A	CLAMP ASSEMBLY, DISTRIBUT	2	
10	10	21335	SCREW, CLAMP TO DISTRIBU	2	
11	13	26996	LOCKWASHER, DISTRIBUTOR	2	
12	43	64907	GEAR, DRIVE (LEFT HAND CRA	1	
12	43	64908	GEAR, DRIVE (RIGHT HAND CF	1	
13	17	58021	PIN, DRIVE GEAR	1	
14	27	58025	"O" RING, DISTRIBUTOR	1	4
14A	35	60047A	SCREEN, FLAME ARRESTOR	2	
15		58258	CLAMP, DISTRIBUTOR TO INTAK	1	
16	10	58259	SCREW, DISTRIBUTOR CLAMP A	1	
16A	13	58260	LOCKWASHER, DISTRIBUTOR C	1	
17	84	65796	LEAD ASSEMBLY, DISTRIBUTOR	1	
18		26433	COIL, IGNITION	1	SERIAL 00000000-04474705
19		33321	BRACKET, IGNITION COIL MOUN	1	SERIAL 00000000-04474705
20	10	33311	SCREW, BRACKET TO IGNITION	1	SERIAL 00000000-04474705
18		32193	COIL, IGNITION	1	SERIAL 04474706-09999999
19		65970	BRACKET, IGNITION, COIL MOUN	1	SERIAL 04474706-09999999
20	10	66652	SCREW, BRACKET TO IGNITION	1	SERIAL 04474706-09999999
21	13	35048	LOCKWASHER, BRACKET SCREW	1	
22	12	30164	WASHER, IGNITION COIL TERMIN	2	
23	13	26996	LOCKWASHER, IGNITION COIL T	2	
24	11	20645	NUT, IGNITION COIL TERMINAL	2	
25	10	34613	SCREW, IGNITION COIL ATTACH	1	
26	12	20553	WASHER, IGNITION COIL ATTAC	1	
27	23	60339	SPACER, IGNITION COIL ATTACH	1	
25	10	26632	SCREW, IGNITION COIL ATTACH	1	
26	12	20553	WASHER, IGNITION COIL ATTAC	1	
27	23	36534	SPACER, IGNITION COIL ATTACH	1	
28	84	67957	LEAD ASSEMBLY, HIGH TENSIO	1	
28	84	67957	LEAD ASSEMBLY, HIGH TENSIO	1	
28	84	67957	LEAD ASSEMBLY, HIGH TENSIO	1	
28	84	67957	LEAD ASSEMBLY, HIGH TENSIO	1	