



**STERN DRIVE**

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		63499	BRACKET, MOUNTING - ENGINE	2		
2	10	68743	SCREW, ENGINE LOCATING	2		
3	11	22024	NUT, ENGINE LOCATING SCREW	2		
4	16	65737	STUD, BRACKET TO ENGINE (2"	3		
4	16	65743	STUD, BRACKET TO ENGINE (3"	1		
5	11	34933	BRACKET, MOUNTING BRACKET	4		
6		66284	BRACKET, MOUNTING	2		
7	11	20739	NUT, JAM-MOUNTING BRACKE	4		
8	13	68102	LOCKWASHER, MOUNTING BRA	2		