

Parts List					Qty	Comment	Footnote
Ref	Class	Part	Description				
1		77124A 2	GIMBAL RING ASSEMBLY	1			
2	31	32538	BEARING, ROLLER - GIMBAL R	1			
3	26	32541	OIL SEAL, GIMBAL RING	2			
4	23	39273	SPACER, GIMBAL RING	1			
5	22	69059	FITTING, GREASE - GIMBAL RII	1			
5A	22	74036	FITTING, GREASE - GIMBAL RINC	2			
6		29359	LUBRICAP, GIMBAL RING GREASE	3			
7		77123	PIN, HINGE - THREADED (WITH I	2			
8		64947	SENDER, DUMMY (STARBOARD)	1			
9	84	70967	HARNESS, DUMMY SENDER	1			
10	10	46342	SCREW, HARNESS ATTACHING	2			
8		63115A 2	SWITCH ASSEMBLY, TRIM LIMIT	1			
9	84	70968	HARNESS, TRIM LIMIT SWITCH	1			
10	10	63400	SCREW, HARNESS ATTACHING	2			
11	85	63990	INSULATOR, SWITCH AND SENC	2			
12	10	37978	SCREW, SWITCH AND SENDER	4			
13	13	26996	LOCKWASHER, SWITCH AND SE	4			
14		57008	RETAINER, SWITCH AND SENDE	4			
15		66545	STEERING LEVER	1			
16		65537	SHAFT, UPPER SWIVEL	1			
17	53	72413	RETAINING RING, UPPER SWIVE	1			
18	11	25599	NUT, UPPER SWIVEL SHAFT	1			
19	22	32561	PLUG, PIPE - UPPER SWIVEL SH	1			
20	12	47683	WASHER, UPPER SWIVEL SHAF	1			
20	12	32997	WASHER, UPPER SWIVEL SHAF	2			
21	10	32995	SCREW, STEERING LEVER TO U	1			
22	11	20696	NUT, STEERING LEVER TO UPPI	1			
23		66388A 1	STEERING LINK ROD ASSEMBLY	1			
24	10	66389	SCREW, LEVER TO LINK ROD	1			
25	12	34966	WASHER, STEERING LINK ROI	1			
26	13	54667	WASHER, SPRING - STEERING	1			
27	12	20086	WASHER, STEERING LINK ROI	2			
28	11	55438	NUT, STEERING LINK ROD	2			
29	18	45882	COTTER PIN, LINK ROD AND S	2			

