



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	32	58432A	TUBING, HYDRAULIC PUMP TO	2		
2	22	49718	NUT, COMPRESSION - HYDRAUL	2		
3	32	59841	HOSE, HYDRAULIC - CONNECTO	1		
4	32	59842	HOSE, HYDRAULIC - CONNECTO	1		
5	32	68676	HOSE, HYDRAULIC - CONNECTO	4		
6		45706A	TRIM CYLINDER ASSEMBLY, COI	2	SEE PAGE 19 FOR REPAIR KIT E	
-		45522A	PIVOT END REPAIR KIT, TRIM	2	SEE PAGE 19 FOR REPAIR KIT E	
-		77332A	OUTER TUBE REPAIR KIT, TRI	2	SEE PAGE 19 FOR REPAIR KIT E	
-	25	60342A	"O" RING REPAIR KIT, TRIM C	2	SEE PAGE 19 FOR REPAIR KIT E	
7	17	45735	PIN, FRONT ANCHOR - TRIM CYL	1		
8	12	45737	WASHER, FRONT ANCHOR PIN	2		
9	23	61290	BUSHING, RUBBER - FRONT ANCH	4		
10	24	46312	SPRING, FRONT ANCHOR PIN	2		
11	12	46765	WASHER, FRONT ANCHOR PIN	2		
12	11	34932	NUT, FRONT ANCHOR PIN	2		
13	17	45738	PIN, REAR ANCHOR - TRIM CYLII	1		
14	12	45737	WASHER, REAR ANCHOR PIN	2		
15	23	61290	BUSHING, RUBBER - REAR ANCH	4		
16	12	46765	WASHER, REAR ANCHOR PIN	2		
17	11	34932	NUT, REAR ANCHOR PIN	2		