


**BREAKDOWN
 OF WATER
 PUMP**



Parts List					Qty	Comment	Footnote
Ref	Class	Part	Description				
1	46	47506A 1	WATER PUMP ASSEMBLY, COM	1			
2		52822	PULLEY, WATER PUMP	1			
3		47530	HUB, WATER PUMP PULLEY	1			
4	10	20705	SCREW, WATER PUMP PULLE	4			
5	13	39107	LOCKWASHER, WATER PUMP	4			
6	26	47401	SHAFT AND BEARING	1			
7	53	47657	RING, RETAINING - SHAFT AN	1			
8	12	47683	WASHER, SHAFT AND BEASRI	1			
9	26	47401	SEAL, MECHANICAL - SHAFT AI	1			
10	26	47531	SEAL, FLOATING - SHAFT AND	1			
11	46	47506A 2	BODY ASSEMBLY, WATER PUM	1			
12		47405	WEAR PLATE	2			
13		47529	INSERT, WATER PUMP BODY	1			
14	47	47519	IMPELLER	1			
15	17	47526	PIN, IMPELLER DRIVE	1			
16		47497A 1	COVER ASSEMBLY, WATER PL	1			
17	23	47511	SLEEVE, WATER PUMP COVE	2			
18	27	47410	GASKET, WATER PUMP COVE	1			
19	10	28635	SCREW, WATER PUMP COVE	6			
20	32	47722A 1	HOSE, WATER PUMP TO OIL CO	1			
21	54	32780	CLAMP, HOSE TO WATER PUMP	2			
22	57	48119	BELT, WATER PUMP	1			
23		47488	BRACKET, WATER PUMP	1			
24	10	34354	SCREW, WATER PUMP BRACKE	1			
25	13	35048	LOCKWASHER, WATER PUMP B	1			
26	10	34353	SCREW, WATER PUMP BRACKE	2			
27	13	35048	LOCKWASHER, WATER PUMP B	2			
28	12	20553	WASHER, WATER PUMP BRACK	1			
29		47544	BRACE, WATER PUMP ADJUSTI	1			
30	10	34353	SCREW, ADJUSTING BRACE TO	1			
31	13	35048	LOCKWASHER, ADJUSTING BRA	1			
32	12	20553	WASHER, ADJUSTING BRACE SI	1			
33	10	35786	SCREW, ADJUSTING BRACE TO	1			
34	13	35048	LOCKWASHER, ADJUSTING BRA	1			
35	11	24883	NUT, ADJUSTING BRACE SCREW	1			