



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		72646	INTKAE MANIFOLD	1	
2	10	26487	BOLT, INTAKE MANIFOLD TO CY	9	
2	10	37510	BOLT, INTAKE MANIFOLD TO CY	3	
3	12	49112	WASHER, INTAKE MANIFOLD BC	3	
4	54	47512	EYE, LIFTING	1	
5	10	34354	SCRE, LIFTING EYE ATTACHING	2	
6	13	35048	LOCKWASHER, LIFTING EYE SCI	2	
7	16	66203	STUD, GUARD TO INTAKE MANII	4	
8		72647	GUARD, INTAKE MANIFOLD	1	
9	27	72637	GASKET SET, INTAKE MANIFOLD	1	
10		60658	WATER PUMP ASSEMBLY	1	4
11	27	34897	GASKET, WATER PUMP MOUN	2	
12	10	52200	SCREW, WATER PUMP TO CYLII	1	3
12	10	32132	SCREW, WATER PUMP TO CYLII	1	
12	10	35346	SCREW, WATER PUMP TO CYLII	1	
12A	16	35342	STUD, WATER PUMP TO CYLINC	1	
13		52349	PULLEY, WATER PUMP	1	
14	10	47277	SCREW, PULLEY TO WATER PU	4	
15	13	39107	LOCKWASHER, WATER PUMP P	4	
16		75420	BALANCER, HARMONIC - CRANK	1	
17		75040	PULLEY, HARMONIC BALANCER	1	
17		33863	PULLEY, HARMONIC BALANCER	1	
18	10	72626	BOLT, PULLEY AND HARMONIC I	1	
19	13	39131	LOCKWASHER, PULLEY AND HA	1	
20	12	35332	WASHER, PULLEY AND HARMOI	1	
21	10	35786	BOLT, CRANKSHAFT PULLEY TO	3	
22	13	35048	LOCKWASHER, CRANKSHAFT PI	3	
23	57	48120	BELT, ALTERNATOR DRIVE (46"	1	
25		35365	SUPPORT, SPARK PLUG LEAD W	2	
26	10	35366	SCREW, LEAD WIRE SUPPORT	2	
27		75612	COVER ASS'Y, CRANKCASE FRC	1	
28	26	59342	OIL SEAL, CRANKCASE FRONT	1	
29	27	34895	GASKET, CRANKCASE FRONT EN	1	3
30	10	34277	SCREW, CRANKCASE FRONT EN	10	
31		75435A	1 POINTER, TIMING	1	
32		53338	FILTER VALVE ASSEMBLY	1	
33	10	54786	SCREW, FILTER VALVE TO CYLI	2	
34		52731	OIL FILTER ASSEMBLY	1	