



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		59861A 4	THERMOSTAT HOUSING ASSEM	1	
2		47511	SLEEVE, THERMOSTAT HOUSI	1	
3	22	47540	PLUG, THERMOSTAT HOUSI	2	
4	22	33198	PLUG, THERMOSTAT HOUSI	1	
5	32	33189	HOSE, THERMOSTAT HOUSING	1	
6	54	32781	CLAMP, HOSE TO THERMOSTAT	2	
7		47441	COVER, THERMOSTAT HOUSI	1	
8	27	48818	GASKET, THERMOSTAT HOUSI	1	4
9		59137	THERMOSTAT (143)	1	
10	27	53045	GASKET, THERMOSTAT HOUSI	1	4
11	10	33389	SCREW, THERMOSTAT HOUSI	2	
12	13	37459	LOCKWASHER, THERMOSTAT H	2	
13		73738	ELBOW, EXHAUST	2	
14	10	60992	SCREW, EXHAUST ELBOW TO E	6	
15	13	35048	LOCKWASHER, EXHAUST ELBO\	6	
16		70981	BELLOWS, EXHAUST ELBOW	2	
17	54	33683	CLAMP, BELLOWS (SMALL)	4	
17	54	31765	CLAMP, BELLOWS (LARGE)	4	
18	25	35029	"O" RING, EXHAUST ELBOW TO	2	
19		60930	SHUTTER, WATER-EXHAUST SE	2	
20		60931	RETAINER, WATER SHUTTER	2	
21		59825	SEPARATOR, EXHAUST	1	
22	10	60835	SCREW, EXHAUST SEPARATOR	1	
23	10	37612	SCREW, EXHAUST SEPARATOR	4	
24	13	35048	LOCKWASHER, EXHAUST SEPA	5	
25	32	77479A 1	HOSE ADAPTOR ASSEMBLY, TH	1	
26	54	32780	CLAMP, HOSE ADAPTOR	2	