



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		62845	SHIFT ACTUATOR ASSEMBLY, C	1		
2	392	4949	ARMATURE	1		
3	392	4960	SPRING SET, BRUSH	1		
4	392	4955	HEAD ASSEMBLY, COMMUTAT	1		
5	392	4956	BRUSH SET	1		
6	392	4962	THRU BOLT	2		
7	392	4950	FIELD COIL ASSEMBLY	1		
8	393	4951	CRANK ARM ASSEMBLY	1		
9	392	4957	HEAD ASSEMBLY, DRIVE END	1		
10	392	4959	SCREW AND DISC PACKAGE	1		
11	392	4952	GEAR AND GASKET PACKAGE	1		
12	392	4953	GASKET, COVER	1		
13	392	4958	PLATE,CAM	2		
14	11	20890	NUT, CRANK ARM	1		
15	10	47220	SCREW, COVER ATTACHING(3	4		
16		66401A 1	HARNESS ASSEMBLY (3WIRE I	1		
17	84	60871A 5	GROUND WIRE ASSEMBLY	1		