



| Parts List |       |          |                               |     |                          |          |
|------------|-------|----------|-------------------------------|-----|--------------------------|----------|
| Ref        | Class | Part     | Description                   | Qty | Comment                  | Footnote |
| 1          | 50    | 65784A 1 | STARTER MOTOR ASSEMBLY (L     | 1   | SEE NOTE INBOARD         |          |
| 1          | 50    | 65785A 1 | STARTER MOTOR ASSEMBLY (R     | 1   | SEE NOTE INBOARD         |          |
| 2          | 10    | 47462    | SCREW, STARTER MOTOR TO F     | 2   | INBOARD                  |          |
| 3          | 13    | 32993    | LOCKWASHER, STARTER MOTO      | 2   | INBOARD                  |          |
| 4          | 11    | 28517    | NUT, STARTER TERMINAL (3/8"   | 1   | INBOARD                  |          |
| 5          | 13    | 26395    | LOCKWASHER, STARTER TERM      | 2   | INBOARD                  |          |
| 6          | 11    | 26419    | NUT, STARTER TERMINAL (#8)    | 1   | INBOARD                  |          |
| 1          | 50    | 56886    | STARTER MOTOR ASSEMBLY (L     | 1   | SEE NOTE STERN DRIVE     |          |
| 2          | 10    | 26632    | SCREW, STARTER MOTOR TO F     | 1   | STERN DRIVE              |          |
| 2          | 16    | 64066    | STUD, STARTER MOTOR TO FL)    | 2   | STERN DRIVE              |          |
| 3          | 13    | 37459    | LOCKWASHER, STARTER MOTO      | 5   | STERN DRIVE              |          |
| 5          | 13    | 26396    | LOCKWASHER, STARTER MOTO      | 1   | STERN DRIVE              |          |
| 5A         | 11    | 32219    | NUT, STARTER MOTOR STUD       | 1   | STERN DRIVE              |          |
| 6          | 11    | 21908    | NUT, STARTER MOTOR TERMIN     | 1   | STERN DRIVE              |          |
| 7          |       | 34625    | WATER TEMPERATURE SENDEL      | 1   |                          |          |
| 8          | 13    | 26396    | LOCKWASHER, WATER TEMPEF      | 1   |                          |          |
| 9          | 11    | 20645    | NUT, WATER TEMPERATURE SE     | 1   |                          |          |
| 10         |       | 34623    | OIL PRESSURE SENDER ASSEM     | 1   |                          |          |
| 11         | 13    | 26396    | LOCKWASHER, OIL PRESSURE S    | 1   |                          |          |
| 12         | 11    | 20645    | NUT, OIL PRESSURE SENDER T    | 1   |                          |          |
| 13         | 22    | 54522    | NIPPLE, OIL PRESSURE SENDEF   | 1   |                          |          |
| 14         | 22    | 56770    | COUPLING, OIL PRESSURE SENI   | 1   | SERIAL 00000000-03415950 |          |
| 14         | 22    | 64485    | FITTING, TEE - OIL PRESSURE S | 1   | SERIAL 33523621-09999999 |          |
| 15         |       | 38559    | SWITCH, OIL PRESSURE (FOR IC  | 1   | SERIAL 33523621-09999999 |          |
| 16         | 12    | 20878    | WASHER, OIL PRESSURE SWI      | 1   | SERIAL 33523621-09999999 |          |
| 17         | 11    | 20645    | NUT, OIL PRESSURE SWITCH      | 1   | SERIAL 33523621-09999999 |          |
| 18         |       | 59755    | ALTERNATOR ASSEMBLY           | 1   |                          |          |
| 19         | 10    | 20055    | SCREW, WIRING HARNESS TO A    | 1   |                          |          |
| 20         | 13    | 26396    | LOCKWASHER, WIRING HARNE      | 1   |                          |          |
| 21         | 12    | 30164    | WASHER, WIRING HARNESS SC     | 1   |                          |          |
| 22         |       | 54479    | BRACE, ALTERNATOR ADJUSTIN    | 1   |                          |          |
| 23         | 10    | 29198    | SCREW, ALTERNATOR BRACE T     | 1   |                          |          |
| 24         | 12    | 26168    | WASHER, ALTERNATOR BRACE      | 1   |                          |          |
| 25         | 10    | 55300    | SCREW, ALTERNATOR BRACE T     | 1   |                          |          |
| 26         | 13    | 39107    | LOCKWASHER, ALTERNATOR BI     | 1   |                          |          |
| 27         |       | 61859    | BRACKET, ALTERNATOR MOUN      | 1   |                          |          |
| 27         |       | 54464    | BRACKET, ALTERNATOR MOUN      | 1   |                          |          |
| 28         | 10    | 48308    | SCREW, ALTERNATOR TO ALTE     | 1   |                          |          |
| 29         | 12    | 20553    | WASHER, ALTERNATOR BRACK      | 2   |                          |          |
| 30         | 23    | 63764    | BUSHING, ALTERNATOR BRACK     | 1   |                          |          |
| 31         | 11    | 22161    | NUT, ALTERNATOR BRACKET S     | 1   |                          |          |