



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	1356	5169	CARBURETOR ASSEMBLY, COM	1	
2			GASKET, THROTTLE BODY	1	3
3	1396	5158	THROTTLE BODY ASSEMBLY	1	
4	1396	4155	LDVER, FUEL PUMP ACTUATIN	1	
5	1396	4133	SCREW, PUMP LEVER ADJUST	1	
6	1396	4105	SPRING, PUMP LEVER ADJUST	1	
7	1396	4089	NUT, PUMP LEVER ADJUSTING	1	
8			RETAINER, PUMP LEVER	1	4
9		N.S.S.	ROD, PRIMARY (NOT SOLD SE	1	
10	1396	5166	CAM, FUEL PUMP	1	
11	1396	4135	SCREW, PUMP CAM ATTACHIN	1	
12	1396	5157	VALVE, PRIMARY THROTTLE	2	
13			SCREW, THROTTLE VALVE AT	8	4
14		N.S.S.	ROD, SECONDARY (NOT SOLD	1	
15	1396	5156	VALVE, SECONDARY THROTTI	2	
16	1396	4146	ROD, SECONDARY CONNECTII	1	
17			COTTER PIN, CONNECTING RC	1	4
18	1396	4144	LEVER, SECONDARY STOP	1	
19	1396	4131	SCREW, SECONDARY STOP LE	1	
20	1396	4127	SCREW, SECONDARY STOP	1	
21	1396	4123	SCREW, THROTTLE STOP	1	
22	1396	4102	SPRING, THROTTLE STOP SCF	1	
23	1396	4128	SCREW, THROTTLE BOTY ATT	8	
24	1396	4643	CHOKE SHAFT AND LEVER AS:	1	
25	1396	4116	VALVE, CHOKE	1	
26			SCREW, CHOKE VALVE TO CHI	2	4
27	1396	4145	LINK, CHOKE	1	
28			SEAL, CHOKE LINK	1	3
29			VALVE, PUMP DISCHARGE	1	4
30			GASKET, DISCHARGE NOZZLE	2	3
31			NOZZLE, PUMP DISCHARGE	1	4
32	1396	4138	SCREW, DISCHARGE NOZZLE	1	
33	1396	5167	HOUSING, SECONDARY DIAPH	1	
34			GASKET, SECONDARY DIAPHR	1	3
35	1396	4129	SCREW, SECONDARY DIAPHR,	3	
36			DIAPHRAGM ASSEMBLY, SECC	1	4
37	1396	4154	LEVER, SECONDARY DIAPHRG	1	
38	1396	4131	SCREW, ADJUSTING - SECONC	1	
39			RETAINER, SECONDARY DIAP	1	4
40	1396	5165	SPRING, RETURN - SECONDAF	1	
41	1396	4084	COVER, SECONDARY DIAPHR	1	