


INBOARD



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		62255	BRACKET, MOUNTING (REAR)	2		
2	10	37269	SCREW, MOUNTING BRACKET T	4		
3	13	32993	LOCKWASHER, MOUNTING BRA	4		
4		61815	BRACKET, MOUNTING (FRONT)	2		
5	16	65737	STUD, FRONT MOUNTING BRAC	3		
5	16	65743	STUD, FRONT MOUNTING BRAC	1	SEE NOTE	
6	12	34567	WASHER, MOUNTING BRACKET	1	SEE NOTE	
6	12	54426	WASHER, MOUNTING BRACKET	4		
7	13	32993	LOCKWASHER, MOUNTING BRA	4		
8	11	34933	NUT, MOUNTING BRACKET STU	4		
9	10	30155	SCREW, ENGINE LOCATING (1	2		
10	11	22024	NUT, ENGINE LCATING SCREW	2		
11	10	47654	SCREW, CLAMP-ADJUSTING TRI	4		
12	13	32993	LOCKWASHER, CLAMP ADJUSTI	4		
13	54	47528	CLAMP, ADJUSTING TRUNNION	8		
14	11	29553	NUT, CLAMP ADJUSTING TRUNN	4		
15	14	48467	TAB WASHER, ADJUSTING TRUI	4		
16		52139A	2 BRACKET ASSEMBLY, MOUNTIN	4		
17	12	48611	WASHER, MOUNTING BRACKE	8		
18		47656	MOUNT, MOUNTING BRACKET	8		
19	10	52156	SCREW, ADJUSTING TRUNNION	4		
20		47518	TRUSSION, ADJUSTING-MOUNT	4		
21	11	47525	NUT, JAM-ADJUSTING TRUNNIO	4		
22	17	22116	PIN, ROL-JAM NUT	4		