



**BREAKDOWN OF  
 WATER PUMP**

**B-46-63450A2**



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	46	63450A 2	WATER PUMP ASSEMBLY, COM	1		
2		59155	COVER, WATER PUMP	1		
3		28635	SCREW, WATER PUMP COVE	6		
4		59712	"O" RING, WATER PUMP COV	1		
5		59504	PLUG, IMPELLER	1		
6		59362	IMPELLER	1		
7		56662	KEY, IMPELLER DRIVE	2		
8		59363A 1	CAM SEGMENT ASSEMBLY, W	1		
9		60777	SCREW< CAM SEGMENT ATTA	1		
10		59503	WEAR PLATE	2		
11		47511	SLEEVE, WATER PUMP COVE	2		
12		23300	OIL SEAL, WATER PUMP SHAF	2		
13		20861	BALL BEARING, WATER PUMP	2		
14		59501	SHAFT, WATER PUMP	1		
15		23720	RING, SNAP - BALL BEARING R	1		
16		59564	OIL SEAL, WATER PUMP SHAF	1		
17		47530	HUB, WATER PUMP PULLEY	1		
18		59762	PULLEY, WATER PUMP	1		
19		54630	SCREW, WATER PUMP PULLEY	4		
20		39107	LOCKWASHER, WATER PUMP P	4		
21		62010	HOSE, PUMP TO OIL COOLER IN	1		
22		32780	CLAMP, WATER PUMP HOSE INE	2		
23		61990	STA STRAP, HOSE ATTACHING	2		
24		61860	BRACE, WATER PUMP ADJUSTI	1		
24		54478	BRACE, WATER PUMP ADJUSTI	1		
25		34353	SCREW, ADJUSTING BRACE TO	1		
26		35048	LOCKWASHER, ADJUSTING BRA	1		
27		20553	WASHER, ADJUSTING BRACE SI	1		
27		34714	WASHER, ADJUSTING BRACE SI	1		
28		37612	SCREW, ADJUSTING BRACE TO	2		
28		26632	SCREW, ADJUSTING BRACE TO	1		
29		34714	WASHER, ADJUSTING BRACE SI	2		
29		20553	WASHER< ADJUSTING BRACE S	1		
30		35048	LOCKWASHER, ADJUSTING BRA	1		
31		32219	NUT, ADJUSTIGN BRACE SCRE	2		
31		28517	NUT, ADJUSTING BRACE SCRE	1		
32		49581	BRACKET, WATER PUMP	1		
33		34354	SCREW, WATER PUMP BRACKE	1		
34		35048	LOCKWASHER, WATER PUMP B	1		
35		52409	SCREW, WATER PUMP BRACKE	1		
36		22185	PUSHING, WATER PUMP BRACK	1		