



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		77011A 7	GIMBAL RING ASSEMBLY	1		
2	26	54927	OIL SEAL, GIMBAL RING	2		
3	31	54928	ROLLER BEARING, GIMBAL RING	1		
4	22	69059	FITTING, GREASE - GIMBAL RING	1		
5		29359	LUBRICAP, GIMBAL RING GREASE	1		
6	23	54002	BUSHING, GIMBAL RING (HINGE)	2		
7	12	54019	WASHER, ANTI-GALLING - BELL	2		
8	17	59812	PIN, HINGE - GIMBAL RING TO H	2		
9	10	45833	SCREW, UPPER SWIVEL SHAFT	1		
10	12	20546	WASHER, UPPER SWIVEL SHAFT	1		
11		63115A 2	SWITCH ASSEMBLY, TRIM LIMIT	1		
12	84	63405	HARNESS, TRIM LIMIT SWITCH	1		
13	10	63400	SCREW, HARNESS ATTACHING	2		
14		64947	SENDER, DUMMY (STARBOARD)	1		
15	84	64987	HARNESS, DUMMY SENDER	1		
16	10	46942	SCREW, HARNESS ATTACHING	2		
17	10	37978	SCREW, TRIM SENDER AND SW	4		
18	13	26996	LOCKWASHER, TRIM SENDER A	4		
19		57008	RETAINER, TRIM SENDER AND	4		
20	85	63990	INSULATOR, SWITCH AND SENC	2		
21		54404	SHAFT, UPPER SWIVEL - GIMBAL	1		
22	22	32561	PLUG, PIPE - UPPER SWIVEL SH	1		
23	12	54026	WASHER, UPPER SWIVEL SHAFT	1		
24	12	54027	WASHER, UPPER SWIVEL SHAFT	1		
25		66545	LEVER, STEERING	1		
26	11	25599	NUT, STEERING LEVER TO UPPER	1		
27	10	68479	SCREW, STEERING LEVER TO UPPER	1		
28	11	34933	NUT, STEERING LEVER SCREW	1		
29		67538A 1	LINK ROD ASSEMBLY, STEERING	1		
30	18	45882	COTTER PIN, RETAINING - STEERING	2		
31	11	55438	NUT, LINK ROD BOLT	1		
32	12	20086	WASHER, LINK ROD	1		
33	11	55438	NUT, LINK ROD	1		
34	10	66389	BOLT, LINK ROD TO STEERING	1		
35	12	34966	WASHER, NYLON - LINK ROD END	1		
36	13	54667	WASHER, WAVE - LINK ROD BOLT	1		
37	12	20086	WASHER, LINK ROD BOLT	1		