



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	32	52951A	1 TUBING, HYDRAULIC PUMP TO V	1		
1	32	58432A	2 TUBING, HYDRAULIC PUMP TO V	1		
2	22	49718	NUT, COMPRESSION-HYDRAULI	2		
3	32	55816	HOSE, HYDRAULIC-CONNECTOR	1		
4	32	59842	HOSE, HYDRAULIC-CONNECTOF	1		
5	32	86036	HOSE, HYDRAULIC-TRIM CYLINC	2		
6		87173A	5 TRIM CYLINDER ASSEMBLY, COI	2	SEE NEXT PAGE FOR REPAIR F	
-		87068A	1 OVERHAUL KIT, TRIM CYLINDE	2	SEE NEXT PAGE FOR REPAIR F	
-	25	60342A	3 SEAL KIT, TRIM CYLINDER	2	SEE NEXT PAGE FOR REPAIR F	
7	17	45735	PIN, FRONT ANCHOR-TRIM CYLI	1		
8	12	45737	WASHER, FRONT ANCHOR PIN	2		
9	23	89574	BUSHING, RUBBER-FRONT ANCI	4		
10	24	46312	SPRING, FRONT ANCHOR PIN	2		
11	12	46765	WASHER, FRONT ANCHOR PIN	2		
12	11	34932	NUT, FRONT ANCHOR PIN	2		
13	17	45738	PIN, REAR ANCHOR (7 1/2")	1		
14	12	45737	WASHER, REAR ANCHOR PIN	2		
15	23	89574	BUSHING, RUBBER-REAR ANCH	4		
16	12	46765	WASHER, REAR ANCHOR PIN	2		
17	11	34932	NUT, REAR ANCHOR PIN	2		
18	32	87234	HOSE, HYDRAULIC-TRIM CYLINC	1		
19	32	87235	HOSE, HYDRAULIC-TRIM CYLINC	1		
20		87057	PLATE, CLAMPING-TRIM CYLIND	2		
21	10	73013	SCREW, CLAMPING PLATE	4		
22	11	45812	NUT, CLAMPING PLATE SCREW	4		