



				Parts List		
Ref	Class	Part	Description	Qty	Comment	Footnote
1	57	77274	V-BELT, PUMP (32 1/2") - LOW M	1		
1	57	91035	V-BELT, PUMP (49 1/2"O - HIGH M	1		
2		73873	PULLEY, STEERING PUMP	1		
3		57611	BRACKET, PUMP (LOW MOUNT)	1		
3		90981A 2	BRACKET, PUMP (HIGH MOUNT)	1		
4	10	32132	SCREW, PUMP TO BRACKET (1 3/4	1		
4	10	40001203	SCREW, PUMP TO BRACKET (45	1		
5	13	35048	LOCKWASHER, PUMP SCREW(N	1		
5	13	40024008	LOCKWASHER, PUMP SCREW(M	1		
6	23	36534	SPACER, PUMP SCREW(NON ME	1		
6	23	90523	SPACER, PUMP SCREW(METRIC	1		
7	10	34354	SCREW, BRACKET TO CYLINDER	2		
8	13	35048	LOCKWASHER, BRACKET SCREW	2		
9	12	38622	WASHER, BRACKET SCREW (FO	1		
10	11	86317	NUT, PUMP STUD(NON METRIC)	1		
10	11	90517	NUT, PUMP STUD(METRIC)	1		
11		49770	OIL COOLER	1	SERIAL 00000000-05045611	
11		77912	OIL COOLER	1	SERIAL 05045612-09999999	
12	54	32781	CLAMP, OIL COOLER TO BRACK	2		
13	54	64324	CLAMP, HOSE ATTACHING TO O	2		
14		49748A 1	BRACKET ASSEMBLY, OIL COOL	1		
15		49735	BRACKET, OIL COOLER MOUNT	1		
16	10	20359	SCREW, OIL COOLER MOUNT BF	1		
17	11	68411	NUT, MOUNT BRACKET SCREW	1		
18	22	37760	ELBOW, OIL COOLER	1		
19		85011A 1	BRACKET, HYDRAULIC PUMP	1		
20	10	26487	SCREW, BRACKET TO PUMP (1 1/2	2		
20	10	40001194	SCREW, BRACKET TO PUMP (30	2		
21	13	35048	LOCKWASHER, BRACKET SCREW	2		
21	13	40024008	LOCKWASHER, BRACKET SCREW	2		
22	23	36365	SPACER, BRACKET SCREW(NON	2		
22	23	90520	SPACER, BRACKET SCREW(MET	2		
23		88777	BRACE, POWER STEERING PUM	1		
24	10	37612	SCREW, BRACE TO BRACKET (1 1/2	OPT		
24	10	34353	SCREWF, BRACE TO BRACKET (1 1/2	OPT		
25	12	34714	WASHER, BRACE SCREW	1		
26	13	35048	LOCKWASHER, BRACE SCREW	1		
27	11	32219	NUT, BRACE SCREW	1		
28	10	76926	SCREW, BRACE TO ENGINE (7/8	1		
29	13	35048	LOCKWASHER, BRACE SCREW	1		