



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		12675A 7	FLYWHEEL HOUSING	1		
2		99297A 1	RUBBER MOUNT	2		
3	23	99322	SPACER	2		
4	10	37612	SCREW	4	(1-1/4 IN.)	
4	10	35870 1	SCREW	2	(2 IN.)	
5	16	64066	STUD	2		
6	11	32219	NUT	2		
7	13	35048	LOCKWASHER	7		
8	12	20572	WASHER	1		
9	54	78945	J-CLAMP	1		
9	54	92850	CLAMP	2		
10		13930A 3	COVER	1	(USE WITH 12 IN. STARTER MO	
10		818719A 1	COVER	1	(USE WITH 8 IN. STARTER MOT	
12	10	32773	SCREW	7		
13	84	62826A 6	WIRE	1		