



19881

Parts List

| Ref | Class | Part     | Description                         | Qty | Comment | Footnote |
|-----|-------|----------|-------------------------------------|-----|---------|----------|
| 1   |       | 97401A 8 | FUEL PUMP                           | 1   |         |          |
| 2   | 27    | 34213    | GASKET, FUEL PUMP TO CYLINE         | 1   |         | 2        |
| 3   | 10    | 34354    | SCREW, (.375-16 x 1.50), FUEL PL    | 2   |         |          |
| 4   | 13    | 35048    | LOCKWASHER, (.375), FUEL PUM        | 2   |         |          |
| 5   |       | 35373    | MOUNTING PLATE, FUEL PUMP           | 1   |         |          |
| 6   | 27    | 34898    | GASKET, FUEL PUMP MOUNTING          | 1   |         | 2        |
| 7   | 10    | 35366    | SCREW, (.250-20 x .563), FUEL PL    | 2   |         |          |
| 8   |       | 35377    | ROD, PUSH - FUEL PUMP               | 1   |         |          |
| 9   |       | 89876A 3 | BASE ASSEMBLY, Fuel Filter/Wate     | 1   |         |          |
| 10  | 22    | 36382    | FITTING, (.250-18 Brass), PIPE - FI | 3   |         |          |
| 11  |       | 88641    | INSULATOR, MOUNTING - FUEL          | 1   |         |          |
| 12  | 10    | 26065    | SCREW, (.312-24 x 1.00), FUEL FII   | 2   |         |          |
| 13  | 11    | 35814    | NUT, (.312-24), FUEL FILTER SCF     | 2   |         |          |
| 14  | 35    | 60494    | FUEL FILTER                         | 1   |         |          |
| 15  | 22    | 33821    | CONNECTOR, FUEL LINE TO FUE         | 3   |         |          |
| 16  | 32    | 97326    | FUEL LINE, FILTER TO FUEL PUM       | 1   |         |          |
| 17  | 32    | 96081A 1 | FUEL LINE, FUEL PUMP TO CARB        | 1   |         |          |
| 18  | 32    | 73815 63 | HOSE, (34.00 Inches Bulk), PLAST    | 1   |         |          |
| -   | 27    | 75611A88 | ENGINE GASKET SET                   | 1   |         |          |