



19898

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		66417	BRACKET, TRANSMISSION (REA	2		
1		52158A20	BRACKET, TRANSMISSION (REA	2		
2	10	37269	SCREW, (.437-14 x 2.00), BRACKE	4		
2	10	47462	SCREW, (.437-14 x 1.250), BRACK	4		
3	13	32993	LOCKWASHER, (.437), BRACKET	4		
4	10	57357	SCREW, (.437-13 x 2.250), CLAMP	2		
4	10	47654	SCREW, (.437-14 X 2.75), CLAMP	2		
5	54	47528	CLAMP, CLAMPING SCREW (HOF	4		
6	13	32993	LOCKWASHER, (.437), CLAMPING	1		
7	11	29553	NUT, (.437-14), CLAMPING SCREW	2		
8		71128A	BRACKET, MOUNTING-ENGINE (I	2		
9	10	68101	SCREW, (.375-16 x 1.375), MOUN	5		
9	10	34354	SCREW, (.375-16 x 1.50), MOUNT	1		
10	13	35048	LOCKWASHER, (.375), MOUNTIN	6		
11	10	57357	SCREW, (.437-13 x 2.250), CLAMP	2		
12	13	32993	LOCKWASHER, (.437), CLAMPING	2		
13	11	29553	NUT, (.437-14), CLAMPING SCREW	2		
14		66166A	TRUNNION, ADJUSTING-MOUNT	4		
15	13	68102	LOCKWASHER, (.750), MOUNTIN	4		
16		66284A	BASE ASSEMBLY, ENGINE MOUN	4		
17	11	20739	NUT, (.750-16), JAM-ENGINE MC	8		
18	14	66658	TAB WASHER, BASE NUT	4		