



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		47737A 1	EXHAUST MANIFOLD ASSEMBLY	1		
1		47738A 1	EXHAUST MANIFOLD ASSEMBLY	1		
2	16	49545	STUD, EXHAUST MANIFOLD TI	8		
3	22	48118	PLUG, EXHAUST MAINFOLD	6		
4	22	32802	PLUG, PIPE - EXHAUST MANIF	2		
5	10	53728	SCREW, EXHAUST MAINFOLD TI	8		
6	27	33395	GASKET, EXHAUST MANIFOLD T	2		
7		52999	END CAP/CONNECTOR, EXHAUS	2		
8	27	48043	GASKET, END CAP/CONNECTOF	2		
9	10	35386	SCREW, END CAP TO EXHAUST	6		
9	10	53016	SCREW, END CAP TO EXHAUST	2		
10		54870	END CAP, EXHAUST MANIFOLD I	2		
11	27	48043	GASKET, END CAP	2		
12	10	25038	SCREW, END CAP TO EXHAUST	8		
13		47877A 1	EXHAUST ELBOW ASSEMBLY (9)	2		
13A		48101A 1	EXHAUST ELBOW ASSEMBLY (S	2		
14	22	32802	PLUG, PIPE - EXHAUST ELBOW	2		
15	32	49705	TUBE, WATER SEPARATION - I	2		
16	22	48118	PLUG, EXHAUST ELBOW	8		
17	27	48042	GASKET, EXHAUST ELBOW TO E	2		
18	13	37459	LOCKWASHER, EXHAUST ELBO	8		
19	11	49838	NUT, EXHAUST ELBOW TO EXH	8		
20	32	47684	HOSE, FLYWHEEL HOUSING TO	1		
21	54	32780	CLAMP, HOSE TO WATER PUMP	2		
22	54	47715	CLIP, HOSE TO CYLINDER BLOC	1		
23	32	33189	HOSE, THERMOSTAT HOUSING	1		
24	54	32781	CLAMP, HOSE TO THERMOSTAT	2		
25	54	53020	CLAMP, WATER PUMP HOSE TO	1		
26		52877A 1	THERMOSTAT HOUSING ASSEM	1		
27	23	47511	SLEEVE, THERMOSTAT HOUSI	1		
28		47441	COVER, THERMOSTAT HOUSIN	1		
29	27	48818	GASKET, THERMOSTAT HOUSIN	1		
30		35884	THERMOSTAT	1		
31	27	47510	GASKET, THERMOSTAT (MIDDLE	1		
32	23	47508	SLEEVE, THERMOSTAT HOUSIN	1		
33	27	53045	GASKET, THERMOSTAT HOUSIN	1		
34	10	48115	SCREW, THERMOSTAT HOUSIN	2	STERN DRIVE	
35	13	37459	LOCKWASHER, THERMOSTAT H	2	STERN DRIVE	
34	10	35785	SCREW, THERMOSTAT HOUSIN	2	INBOARD	
36	32	48131	HOSE, THERMOSTAT HOUSING	2		
37	54	32780	CLAMP, HOSE TO THERMOSTAT	4		