


**BREAKDOWN
 OF WATER
 PUMP**



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	46	58001A 4	WATER PUMP ASSEMBLY, COM	1		
2	26	23300	OIL SEAL, WATER PUMP SHAF	2	INBOARD	
3	30	20861	BALL BEARING, WATER PUMP	2	INBOARD	
4		57967	SHAFT, WATER PUMP	1	INBOARD	
5	53	23720	RING, SNAP - BALL BEARING R	1	INBOARD	
6	26	58111	OIL SEAL, WATER PUMP SHAF	1	INBOARD	
7	26	47531	SEAL, FLOATING - WATER PUK	1	STERN DRIVE	
8	26	47401	SEAL, MECHANICAL - WATER F	1	STERN DRIVE	
9	12	47683	WASHER, WATER PUMPM SH/	1	STERN DRIVE	
10	53	47657	RING, RETAINING - WATER PU	1	STERN DRIVE	
11		47403	SHAFT, WATER PUMP	1	STERN DRIVE	
12		47530	HUB, WATER PUMP PULLEY	1		
13		47405	WEAR PLATE	2		
14		47529	INSERT, WATER PUMP	1		
15	47	47519	IMPELLER	1		
16	17	47526	PIN, IMPELLER DRIVE	1		
17		47497A 1	COVER ASSEMBLY, WATER PL	1		
18	23	47511	SLEEVE, WATER PUMP COVE	2		
19	27	47410	GASKET, WATER PUMP COVE	1		
20	10	28635	SCREW, WATER PUMP COVE	6		
21		52822	PULLEY, WATER PUMP	1		
22	10	20705	SCREW, WATER PUMP PULLEY	4		
23	13	39107	LOCKWASHER, WATER PUMP P	4		
24	32	47722A 1	HOSE, WATER PUMP TO OIL CO	1		
25	54	32780	CLAMP, HOSE TO WATER PUMP	2		
26	57	48119	BELT, WATER PUMP	1		
27		47488	BRACKET, WATER PUMP	1		
28	10	34354	SCREW, WATER PUMP BRACKE	1		
29	13	35048	LOCKWASHER, WATER PUMP B	1		
30	10	34353	SCREW, WATER PUMP BRACKE	2		
31	13	35048	LOCKWASHER, WATER PUMP B	2		
32	12	20553	WASHER, WATER PUMP BRACK	1		
33		47544	BRACE, WATER PUMP ADJUSTI	1		
34	10	34353	SCREW, ADJUSTING BRACE TO	1		
35	13	35048	LOCKWASHER, ADJUSTING BRA	1		
36	12	20553	WASHER, ADJUSTING BRACE SI	1		
37	10	35786	SCREW, ADJUSTING BRACE TO	1		
38	13	37459	LOCKWASHER, ADJUSTING BRA	1		
39	11	24883	NUT, ADJUSTING BRACE SCREW	1		