



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		56717	PANEL, ELECTRIC	1		
2	19	32298	PLUG, ELECTRIC PANEL (STERN	2		
3	25	57009	GROMMET, TRIGGER LEADS - EI	1		
4		25661	STARTER SOLENOID	1		
5	13	26993	LOCKWASHER, STARTER SOLEI	2		
6	11	20083	NUT, STARTER SOLENOID TERM	2		
7	13	26996	LOCKWASHER, STSRTER SOLEI	2		
8	11	20645	NUT, STARTER SOLENOID TERM	2		
9	10	26774	SCREW, STSRTER DOLENOID TC	2		
10	13	26992	LOCKWASHER, STARTER SOLEI	2		
11	10	26632	SCREW, ELECTRIC PANEL TO C	1		
12	10	35787	SCREW, ELECTRIC PANEL TO C	1		
13	10	47954	SCREW, ELECTRIC PANEL TO FL	1		
14	13	35048	LOCKWASHER, ELECTRIC PANE	3		
15	12	20553	WASHER, ELECTRIC PANEL SCF	3		
16	25	47624	GROMMET, ELECTRIC PANEL	1		
17	332	2986A 8	SWITCH BOX ASSEMBLY	1		
18	12	45075	WASHER, SWITCH BOX TERMIN	7		
19	13	26996	LOCKWASHER, SWITCH BOX TE	7		
20	11	45076	NUT, SWITCH BOX TERMINAL	7		
21	10	26184	SCREW, SWITCH BOX TO ELECT	4		
22	13	21547	LOCKWASHER, SWITCH BOX SC	4		
23	10	45218	SCREW, GROUND WIRE TO SWI	1		
24	332	2983A 6	IGNITION COIL ASSEMBLY	1		
25	10	45103	SCREW, IGNITION COIL CLAMP	2		
26	11	20190	NUT, IGNITION COIL SCREW	2		
27	10	26889	SCREW, IGNITION COIL TO ELEC	2		
28	13	26992	LOCKWASHER, IGNITION COIL S	2		
29	37	56021	DECAL, WIRING	1		
30		38371	SEAL, COVER TO ELECTRIC PAN	1		
31	37	56021	DECAL, ELECTRIC COVER (270 H	1		
32		47550	COVER, ELECTRIC PANEL	1		
33	10	47674	SCREW, COVER TO ELECTRIC P.	8		
34		56387	WIRING HARNESS, INTERNAL	1		
35		48459	PLATE, BACKUP - WIRING HARN	1		
36	10	46718	SCREW, BACKUP PLATE FASTEN	4		
37		47764	STA-STRAP, WIRING HARNESS	1		
38	54	46721	CLIP, WIRING HARNESS ATTACH	2		
39	10	20367	SCREW, WIRING HARNESS CLIP	2		
40	13	26992	LOCKWASHER, WIRING HARNE	2		
41		28974	CONNECTOR, TRIM INDICATOR	2		