



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
		48639A	1 EXHAUST KIT	1		
1	32	48659	2 HOSE, EXHAUST	2		
2	54	33683	CLAMP, HOSE ATTACHING	16		
3		48639	PIPE, EXHAUST	2		
4	32	33645	TUBE, EXHAUST - EXHAUST H	2		
5		35013	FLANGE, EXHAUST HOSE	2		
6	27	33600	GASKET, EXHAUST HOSE FLA	2		
7	10	33684	SCREW, HOSE FLANGE TO BO.	6		
8	12	25908	WASHER, ESHAUST HOSE FLA	6		
9	11	20361	NUT, EXHAUST HOSE FLANGE	6		
10		34765A	1 COVER KIT, EXHAUST FLANGE	1		
11	54	33683	CLAMP, COVER TO FLANGE	2		