



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		54794	INTAKE MANIFOLD	1		
2	10	26487	BOLT, INTAKE MANIFOLD TO CY	8		
2	10	52200	BOLT, INTAKE MANIFOLD TO CY	4		
3	22	48336	PLUG, PIPE - INTAKE MANIFOLD	1		
4	54	47512	EYE, LIFTING	2		
5	10	34354	SCREW, LIFTING EYE ATTACHIN	4		
6	13	35048	LOCKWASHER, LIFTING EYE SCI	4		
7	16	52228	STUD, GUARD TO INTAKE MANIF	4		
8		54795	GUARD, INTAKE MANIFOLD	1		
9	27	54792	GASKET SET, INTAKE MANIFOLD	1		
10		54793	WATER PUMP ASSEMBLY	1		
11	27	34897	GASKET, WATER PUMP MOUN	2		
12	27	35380	GASKET, WATER PUMP BACK	1		
13	22	48336	PLUG, PIPE - WATER PUMP	1		
14	10	48424	SCREW, WATER PUMP TO CYLIN	3		
14	10	47688	SCREW, WATER PUMP TO CYLIN	1		
15		52349	PULLEY, WATER PUMP	1		
16	10	47277	SCREW, PULLEY TO WATER PU	4		
17	13	39107	LOCKWASHER, WATER PUMP P	4		
18		58210	BALANCER, HARMONIC - CRANK	1		
19		33863	PULLEY, HARMONIC BALANCER	1		
20	10	34281	BOLT, PULLEY AND HARMONIC	1		
21	13	39131	LOCKWASHER, PULLEY AND HA	1		
22	12	35332	WASHER, PULLEY AND HARMON	1		
23	10	34352	BOLT, CRANKSHAFT PULLEY TO	3		
24	13	35048	LOCKWASHER, CRANKSHAFT PI	3		
25	57	48120	BELT, ALTERNATOR DRIVE (46"	1		
26	841	4301	CYLINDER BLOCK ASSEMBLY (SI	1		
27		35365	SUPPORT, SPARK PLUG LEAD W	2		
28	10	35366	SCREW, LEAD WIRE SUPPORT	2		
29	13	35367	LOCKWASHER, LEAD WIRE SUP	2		
30		36184	SHAFT, OIL PUMP TO DISRIBUT	1		
31	23	36183	RETAINER, OIL PUMP SHAFT	1		
32		35352	OIL PUMP ASSEMBLY	1		
33	10	48333	BOLT, OIL PUMP TO CYLINDER	1		
34		35354	SCREEN ASSEMBLY, OIL PUMP	1		
35		53338	FILTER VALVE ASSEMBLY	1	ENGINE WITH OIL FILTER ON C	
36	10	36404	SCREW, FILTER VALVE TO CYLIN	2	ENGINE WITH OIL FILTER ON C	
35		54785	ADAPTOR ASSEMBLY, OIL FILTE	1	ENGINE WITH OIL FILTER ON E	
36	10	54786	SCREW, ADAPTOR TO CYLINDE	2	ENGINE WITH OIL FILTER ON E	
37		52721	OIL FILTER ASSEMBLY (STERN	1		