



| Parts List | | | | | | |
|------------|-------|---------|------------------------------|---------|---------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| 1 | | 47805 | TRANSMISSION (DIRECT DRIVE) | 1 | | |
| 1 | | 47806 | TRANSMISSION (1.523:1 REDUC | 1 | | |
| 1 | | 47807 | TRANSMISSION (1.909:1 REDUC | 1 | | |
| 1 | | 47808 | TRANSMISSION (2.57:1 REDUC | 1 | | |
| 1 | | 47809 | TRANSMISSION (2.909:1 REDUC | 1 | | |
| 2 | 10 | 47724 | SCREW, TRANSMISSION TO EN | 4 | | |
| 2 | 10 | 47724 | SCREW, TRANSMISSION TO EN | 6,6,6,6 | | |
| 3 | 16 | 45199 | STUD, TRANSMISSION TO ENGI | 2 | | |
| 4 | 13 | 32993 | LOCKWASHER, TRANSMISSION | 6,6,6,6 | | |
| 5 | 11 | 22024 | NUT, TRANSMISSION STUD | 2 | | |
| 6 | 22 | 47629 | ELBOW, HOSE TO TRANSMISSIC | 1,1,1,1 | | |
| 7 | 32 | 47516 1 | HOSE, OIL COOLER TO TRANSM | 1 | | |
| 7 | 32 | 47516 3 | HOSE, OIL COOLER TO TRANSM | 1,1,1,1 | | |
| 8 | 22 | 47630 | ELBOW, HOSE TO OIL COOLER (| 1,1,1,1 | | |
| 9 | | 47613 | SWITCH, NEUTRAL SAFETY | 1,1,1,1 | | |
| 10 | | 48381 | FLANGE (1") | OPT..0 | | |
| 10 | | 48382 | FLANGE (1 1/8") | OPT..0 | | |
| 10 | | 48383 | FLANGE (1 1/4") | OPT..0 | | |
| 10 | | 48384 | FLANGE (1 3/8") | OPT..0 | | |
| 10 | | 48385 | FLANGE (1 1/2") | OPT..0 | | |
| 11 | | 48648 | BRACKET, SHIFT CABLE | 1,1,1,1 | | |
| 12 | 12 | 37407 | WASHER, SHIFT CABLE TO BRAI | 1,1,1,1 | | |
| 13 | 11 | 46438 | NUT, SHIFT CABLE TO BRACKET | 1,1,1,1 | | |
| 14 | 22 | 47629 | ELBOW, HOSE TO TRANSMISSIC | 1 | | |
| 15 | 23 | 36159 | BUSHING, REDUCING - TRANSM | 1,1,1,1 | | |
| 16 | 22 | 47631 | ELBOW, HOSE TO TRANSMISSIC | 1,1,1,1 | | |
| 17 | 32 | 47516 4 | HOSE, TRANSMISSION TO OIL C | 1 | | |
| 17 | 32 | 47516 2 | HOSE, TRANSMISSION TO OIL C | 1,1,1,1 | | |
| 18 | 22 | 47630 | ELBOW, HOSE TO OIL COOLER (| 1,1,1,1 | | |
| 19 | | 48515 | LEVER, SHIFT - TRANSMISSION | 1,1,1,1 | | |
| 20 | 12 | 20722 | WASHER, SHIFT LEVER TO TRA | 1,1,1,1 | | |
| 21 | 13 | 26993 | LOCKWASHER, SHIFT LEVER TC | 1,1,1,1 | | |
| 22 | 11 | 20083 | NUT, SHIFT LEVER TO TRANSMI | 1,1,1,1 | | |
| 23 | | 48652 | ADAPTOR, SHIFT CABLE TO SHII | 1,1,1,1 | | |
| 24 | 16 | 48680 | STUD, SHIFT CABLE ADAPTOR T | 1,1,1,1 | | |
| 25 | 12 | 20533 | WASHER, SHIFT CABLE ADAPTC | 1,1,1,1 | | |
| 26 | 11 | 46887 | NUT, SHIFT CABLE ADAPTOR ST | 1,1,1,1 | | |
| 27 | 13 | 29402 | WAVE WASHER, SHIFT CABLE A | 1,1,1,1 | | |
| 28 | 12 | 37407 | WASHER, SHIFT CABLE ADAPTC | 1,1,1,1 | | |
| 29 | 11 | 46438 | NUT, SHIFT CABLE ADAPTOR ST | 1,1,1,1 | | |
| 30 | 10 | 20629 | SCREW, SHIFT CABLE TO ADAP | 1,1,1,1 | | |