



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		70938	BRACKET, MOUNTING - ENGINE	2		
2	10	37612	SCREW, MOUNTING BRACKET T	3		
3	13	35048	LOCKWASHER, MOUNTING BRA	3		
2	10	37612	SCREW, MOUNTING BRACKET T	1		
3	13	35048	LOCKWASHER, MOUNTING BRA	1		
2	10	48424	SCREW, MOUNTING BRACKET T	2		
3	13	35048	LOCKWASHER, MOUNTING BRA	2		
4		66284	BRACKET, MOUNTING	2		
5	11	20739	NUT, JAM - MOUNTING BRACK	4		
6	13	68102	LOCKWASHER, MOUNTING BRA	2		