



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	57	49756	V-BELT, STEERING PUMP	1	SERIAL 04499390 AND BELOW	
1	57	74270	V-BELT, STEERING PUMP	1	SERIAL 04499391 AND THRU 42	
1	57	77274	V-BELT, STEERING PUMP	1	SERIAL 04499781 AND UP	
2		48086A 1	PULLEY ASSEMBLY, CRANKSHA	1	SERIAL 04499780 AND BELOW	
3	10	48308	SCREW, PULLEY TO DAMPER	3	SERIAL 04499780 AND BELOW	
4	13	35048	LOCKWASHER, PULLEY SCREW	3	SERIAL 04499780 AND BELOW	
2		75040	PULLEY, CRANKSHAFT	1	SERIAL 04499781 AND UP	
3	10	35786	SCREW, PULLEY ATTACHING	3	SERIAL 04499781 AND UP	
4	13	35048	LOCKWASHER, PULLEY SCREW	3	SERIAL 04499781 AND UP	
5		71137	PULLEY, STEERING PUMP	1	SERIAL 04499390 AND BELOW	
5		73873	PULLEY, STEERING PUMP	1	SERIAL 04499391 AND UP	
6		71136	HUB, STEERING PUMP	1	SERIAL 04499390 AND BELOW	
7	10	62049	SCREW, PULLEY TO HUB (1")	4	SERIAL 04499390 AND BELOW	
8	13	39107	LOCKWASHER, PULLEY SCREW	4	SERIAL 04499390 AND BELOW	
9		57611	BRACKET, PUMP MOUNTING	1		
10	10	34354	SCREW, STEERING PUMP TO BF	1		
11	13	35048	LOCKWASHER, STEERING PUMF	1		
12	23	36534	SPACER, STEERING PUMP SCRE	1		
13	10	37612	SCREW, BRACKET TO CYLINDEF	2		
14	13	35048	LOCKWASHER, BRACKET SCREW	2		
15	12	38622	WASHER, BRACKET SCREW (FO	1		
16	11	52412	NUT, STEERING PUMP STUD	1		
17		49770	OIL COOLER	1		
18	54	32781	CLAMP, OIL COOLER TO BRACKE	2		
19	54	64324	CLAMP, HOSE ATTACHING TO O	2		
20		49748A 1	BRACKET, OIL COOLER	1		
21		49735	BRACKET, OIL COOLER MOUNT	1		
22	10	27165	SCREW, OIL COOLER MOUNT BF	1		
23	11	52412	NUT, MOUNT BRACKET SCREW	1		
24	22	37760	ELBOW, OIL COOLER	2		
25	10	48424	SCREW, BRACKET TO ENGINE (2		
26	13	35048	LOCKWASHER, BRACKET SCREW	2		
27	23	36365	SPACER, BRACKET SCREW	2		