



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	32	60058	HOSE, COVER TO DIST. HSG. (S)	1	SERIAL 04499390 AND BELOW	6
2	32	60057	HOSE, COVER TO DIST. HSG. (P)	1	SERIAL 04499390 AND BELOW	6
3	32	59876	HOSE, HSG. TO EXH. MAN. (REA)	2	SERIAL 04499390 AND BELOW	6
1 & 2	32	73796	HOSE, COVER TO EXH. MAN. (RE)	2	SERIAL 04499391 AND BELOW	
3	32	73794	HOSE, HSG. TO EXH. MAN. (STB)	1	SERIAL 04499391 AND BELOW	
3	32	73795	HOSE, HSG. TO EXH. MAN. (POR)	1	SERIAL 04499391 AND BELOW	
4	32	48132	HOSE, THERMOSTAT HOUSING	2		
5	32	71613	HOSE, THERMOSTAT HOUSING	1		
6	54	47715	CLIP, HOSE TO CYLINDER BLOC	1		
7	54	32780	CLAMP, HOSE TO OIL COOLER A	2		
8	54	32880	CLAMP, HOSE ATTACHING	12		