



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		99237A10	SHIFT BRACKET ASSEMBLY (EAF)	1	
2	16	98798	STUD, SHIFT CABLE	1	
3	16	96108	STUD, SHIFT BRACKET	2	
4		13051A 4	LEVER ASSEMBLY, ACTUATING	1	
5	24	45599	SPRING, ACTUATING LEVER	1	
6	10	88743	SCREW, SPRING TO LEVER	1	
7	12	56720	WASHER, SPRING SCREW	1	
8	23	98828	SPACER, RUBBER PAD	1	
9	18	32857	COTTER PIN, SHIFT CABLE RETA	1	
10	12	56720	WASHER, SHIFT BRACKET STUC	5	
11	23	37981	SPACER, SHIFT BRACKET STUD	2	
12	23	45600	SLEEVE, ACTUATING LEVER	1	
13	11	35814	NUT, SHIFT BRACKET STUD	2	
14		39670A28	SWITCH ASSEMBLY, CUT-OUT	1	
15	10	30902	SCREW, SWITCH TO SHIFT BRA	2	
16	86	66986	TERMINAL BLOCK	1	
17	10	96113	SCREW, TERMINAL BLOCK (7/8"	1	
18	10	73287	SCREW, TERMINAL BLOCK (3/8"	1	
19	13	26996	LOCKWASHER, TERMINAL BLOC	2	
20		13898A 3	SHIFT LEVER ASSEMBLY	1	
21	16	98851	STUD, SHIFT CABLE	1	
22	23	45600	SLEEVE, SHIFT LEVER	1	
23	16	96112	STUD, SHIFT CABLE	1	
24	12	35462	WASHER, SHIFT CABLE STUD	4	
25	11	63341	TEE NUT, SHIFT CABLE STUD	1	
26	23	98820	SPACER, SHIFT CABLE STUD	1	
27	24	98880	SPRING, SHIFT CABLE STUD	1	
28	11	20361	NUT, SHIFT CABLE STUD	3	