



| Parts List | | | | | | |
|------------|-------|--------|-----------------------------|-----|---------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| 1 | | 98626A | 3 EXHAUST SEPARATOR | 1 | | |
| 4 | 25 | 35029 | "O" RING | 1 | | |
| 5 | | 60931 | RETAINER, WATER SHUTTER | 1 | | |
| 7 | | 94018A | 1 EXHAUST ELBOW ASSEMBLY | 1 | | |
| 8 | 10 | 58640 | SCREW, EXHAUST ELBOW TO S | 3 | | |
| 9 | 13 | 58643 | LOCKWASHER, EXHAUST ELBO | 3 | | |
| 10 | 32 | 48659 | 4 HOSE, EXHAUST | 2 | | |
| 11 | 54 | 33683 | CLAMP, EXHAUST HOSE | 10 | | |
| 12 | | 94608A | 1 EXHAUST TUBE ASSEMBLY | 1 | | |
| 13 | | 41191A | 1 EXHAUST ELBOW ASSEMBLY | 1 | | |
| 14 | | 70981A | 3 EXHAUST BELLOWS | 1 | | |
| 15 | | 95740 | GROUND STRAP, EXHAUST BEL | 1 | | |
| 16 | 54 | 31765 | CLAMP, EXHAUST BELLOWS | 2 | | |
| 17 | | 41063A | 1 BRACKET ASSEMBLY, MOUNTIN | 1 | | |
| 18 | 10 | 24231 | SCREW, BRACKET | 1 | | |
| 19 | 11 | 46438 | NUT, BRACKET SCREW | 1 | | |
| 20 | | 45915 | 1 TERMINAL BLOCK | 1 | | |
| 21 | | 93925A | 1 PLATE, EXHAUST SEPARATOR | 1 | | |
| 22 | 10 | 98794 | SCREW, PLATE | 3 | | |
| 23 | 13 | 58643 | LOCKWASHER, PLATE SCREW | 3 | | |