



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	84	98422A10	HARNESS (CONVENTIONAL IGNI	1		
2	84	98422A17	HARNESS (DIGITAL IGNITION - 3	1		
2	84	98422A14	HARNESS (DIGITAL IGNITION - 3	1		
2	84	98422A18	HARNESS (EST IGN.)	1	SERIAL Q4000000-0F114599	
2	84	806217A11	HARNESS (EST IGN.)	1	SERIAL 0F114600-0Z999999	
N/S		817374A01	CONNECTOR-Delco EST Distribut	1		
3		26079A 2	PLATE ASSEMBLY (CONVENTION	1		
4	10	15001	SCREW (IGNITION)	4		
5		97257A 1	WATER TEMPERATURE SENDEI	1		
5		49734A 1	WATER TEMPERATURE SENDEI	OPT..		
6	13	26996	LOCKWASHER (#10)	1		
7	11	68219	NUT (#10)	1		
8		815425	OIL PRESSURE SENDER	1		
8		37293	OIL PRESSURE SENDER (DUAL)	OPT..		
9	13	26996	LOCKWASHER (#10)	1		
10	11	68219	NUT (#10)	1		
11	22	32974	ADAPTOR	1		
12	88	11178	CIRCUIT BREAKER (50 AMP)	1		
13	13	26996	LOCKWASHER	2		
14	11	68219	NUT	2		
15	10	45862	SCREW (7/8")	2		
16	11	61356	NUT	2		
17	89	96158	STARTER SOLENOID	1		
18	10	98256	SCREW	2		
19	11	35045	NUT	2		
20	13	26992	LOCKWASHER	2		
21	11	26419	NUT (10-32)	2		
22	11	94330	NUT (1/4-20)	2		
23		98428T 3	BRACKET (CONVENTIONAL/EST	1		
24		815414T	BRACKET (DIGITAL IGNITION)	1		
25	84	94227A 2	RESISTANCE CABLE KIT (TO REF	1		
26	85	97861	INSULATOR	1		