



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		816129A 1	DISTRIBUTOR ASSEMBLY	1		
2		810827	DISTRIBUTOR CAP	1		
3	392	9089	ROTOR	1		
4		810836	PLATE ASSEMBLY	1		
5	392	6325	BREAKER SET	1		
6	392	6324	CONDENSER	1		
7		810824	BEARING AND PARTS KIT	1		
8		810826	CAM RETAINER	1		
9		810835	SHAFT AND CAM ASSEMBLY	1		
10	24	810830	SPRING SET	1		
11		810829	PRIMARY WIRE	1		
12		810828	GEAR AND PARTS KIT	1		
13		810825	BRACKET KIT	1		
14	27	87707	GASKET	1		2
15		72624	CLAMP UNIT	1		
16	10	12244	SCREW	1		
17	84	816761A 5	SPARK PLUG WIRE KIT	1		
18	85	63709A 1	PROTECTOR	4		
19	33	59571	SPARK PLUG	4		
20		54676	RETAINER	1		
21		32783	RETAINER	1		
22	392	806529A 1	IGNITION COIL	1		
23		65970T 1	BRACKET	1		
24	10	41408	SCREW	1		
25	12	30164	WASHER	2		
26	13	26996	LOCKWASHER	2		
27	11	68219	NUT	2		
28	10	98261	SCREW	1		
29	12	20553	WASHER	1		