



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-	50	99417A 2	STARTER MOTOR ASSEMBLY	1		
1		71696	HOUSING	1		
2	23	33369	BUSHING	1		
3		814474	COLLAR	1		
4	53	33290	RING	1		
5		33291	COLLAR	1		
6		79205	DRIVE ASSEMBLY	1		
7		N.S.S.	BEARING PLATE (DELCO-REMY)	1		
8	23	71694	BUSHING	1		
9	12	68614	WASHER	1		
10	10	79209	SCREW	2		
11		75665	ARMATURE	1		
12		N.S.S.	POLE SHOE (DELCO-REMY #81	4		
13		N.S.S.	SCREW (DELCO-REMY #19683	4		
14	25	79208	GROMMET	1		
15		75664	FIELD COIL ASSEMBLY	1		
16	12	33258	LEATHER WASHER	1		
17		79211	FRAME	1		
18		N.S.S.	THRU BOLT (DELCO-REMY #19	1		
18		N.S.S.	THRU BOLT (W/EXTENSION D	1		
19		33284	HOLDER	2		
20		33283	HOLDER	2		
21		33270	BRUSH	4		
22		N.S.S.	SCREW (DELCO-REMY #44352	2		
23		33294	SUPPORT PACKAGE	2		
24	24	33285	SPRING	4		
25		N.S.S.	DOWEL PIN (DELCO-REMY #8C	1		
26		71698	SHIFT LEVER	1		
27		N.S.S.	PIN (DELCO-REMY #1945804)	1		
28	53	33354	RETAINING RING	1		
29		N.S.S.	PLUNGER (DELCO-REMY #197	1		
30	17	79207	PIN	1		
31		N.S.S.	SPRING (DELCO-REMY#19782	1		
32		N.S.S.	SCREW (DELCO-REMY #94132)	2		
33	89	18080	SOLENOID SWITCH (3-5/8" LO	1		