



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		98348A 4	INTAKE MANIFOLD ASSEMBLY	1		
2	22	32802	PLUG, INTAKE MANIFOLD - TOI	1		
3	10	28642	DRIVE SCREW, WATER TUBE	4		
4	27	70905	GASKET, INTAKE MANIFOLD	1		2
5	10	68101	SCREW, INTAKE MANIFOLD TO (	7		
6	12	25909	WASHER, INTAKE MANIFOLD SC	5		
6	12	55149	WASHER, INTAKE MANIFOLD SC	2		
7	22	73817	FITTING, INTAKE MANIFOLD	1		
8	32	89713	HOSE, INTAKE MANIFOLD TO RE	1		
9	54	54428	CLAMP, HOSE ATTACHING	2		
10		98350A 1	COVER, OIL COOLER	1		
11	25	42357	"O" RING, OIL COOLER COVER	1		
12	10	76596	SCREW, OIL COOLER COVER	10		
13	13	26992	LOCKWASHER, COVER SCREW	10		
14	32	76326	HOSE, INTAKE MANIFOLD TO W	1		
15	54	32780	CLAMP, HOSE TO WATER PUMP	1		
16	54	32781	CLAMP, HOSE TO INTAKE MANIF	1		
17	32	89655	HOSE, INTAKE MANIFOLD	1		
18	54	32781	CLAMP, HOSE TO INTAKE MANIF	2		