



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	45	86978A 1	DRIVE SHAFT ASSEMBLY	1		
2		61218	FLANGE DRIVE SHAFT	1		
3		61221	CROSS AND BEARING	2		
4	22	74036	GREASE FITTING	2		
5		86692	YOKE	1		
6		61219	U-BOLT, DRIVE SHAFT TO TRAN	2		
7	11	23161	NUT, U-BOLT	4		
8	10	92154	SCREW, DRIVE SHAFT TO TAILS	4		
9	12	45176	WASHER, DRIVE SHAFT SCREW	4		
10		68488	SHAFT, TAILSTOCK	1		
11	30	62780A 1	BALL BEARING	1		
12	53	68487	SNAP RING	1		
13	53	68486	SNAP RING	1		
14		68485A 2	TAILSTOCK HOUSING	1		
15	22	74036	GREASE FITTING	1		
16		62739A 2	HOUSING, OUTPUT	1		
17	30	62780A 1	BALL BEARING	1		
18	16	32027	STUD	6		
19	11	24652	NUT	6		
20	10	74824	SCREW	6		
21	13	39107	LOCKWASHER	6		
22		65389	RETAINER, BALL BEARING	1		
23	22	74036	GREASE FITTING	1		
24	19	77633	LUBRICAP, GREASE FITTING	1		
25		62734	MOUNT, RUBBER-OUTPUT HOU	1		
26	10	67630	SCREW, TAILSTOCK TO TRANSC	2		
27	12	36258	WASHER, TAILSTOCK SCREW	4		
28	11	52901	NUT, TAILSTOCK SCREW	2		