



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		92043A 3	BRACKET, OIL FILTER	1		
2		32720	ADAPTOR	1		
3	27	91892	GASKET, ADAPTOR COVER AND	2		11
4	35	99884	OIL FILTER	1		
5		90783A13	ADAPTOR ASSEMBLY, OIL FILTE	1		
6		34344	VALVE, BY-PASS	1		
7		32720	ADAPTOR	1		
8	22	48246	ELBOW, OIL HOSE	1		
8	22	63825	ELBOW, OIL HOSE	1		
9	25	62700	"O" RING, OIL FILTER ADAPTOR	1		11
10	27	99893	GASKET, OIL FILTER ADAPTOR	1		11
11	10	91966	SCREW, OIL FILTER ADAPTOR (1		
11	10	91967	SCREW, OIL FILTER ADAPTOR (1		
12		91830	COVER, ADAPTOR	1		
13	32	92357 59	HOSE, OIL-ADAPTOR (34") MR	1		
14	32	92357 9	HOSE, OIL-ADAPTOR (7") MR	1		
14	32	92357 69	HOSE, OIL-ADAPTOR (44") MR	1		
13	32	92357 59	HOSE, OIL-ADAPTOR (34") TR	2		
14	32	92357 49	HOSE, OIL-ADAPTOR (24") TR	1		
15	22	63825	FITTING, HOSE TO OIL COOLER-	2		
15	22	47630	FITTING, HOSE TO OIL COOLER-	2		
16		89690T	OIL COOLER, ENGINE MR	1		
17		63820 1	BRACKET, OIL COOLER (LONG) I	1		
18		56328A 1	BRACKET, OIL COOLER (SHORT)	1		
19	10	69028	SCREW, OIL COOLER BRACKET	2		
20	11	20361	NUT, OIL COOLER BRACKET SCF	2		