



				Parts List		
Ref	Class	Part	Description	Qty	Comment	Footnote
1		12987A 2	PLENUM ASSEMBLY	1		
2	22	13757	NIPPLE	1		
3	22	32561	PLUG	1		
4	27	13745	GASKET, PLENUM	1		3
5	10	70084	SCREW, PLENUM TO INTAKE MA	8		
6	12	29245	WASHER, PLENUM SCREW	8		
7	89	14561A 1	AIR VALVE	1		
8	27	14527	GASKET	1		3
9	10	76566	SCREW	2		
10	13	26996	LOCKWASHER	2		
11		14882A 2	INDICATOR, THROTTLE POSITIC	1		
12	10	86509	SCREW	2		
13	13	26995	LOCKWASHER	2		
14	12	30164	WASHER	2		
15		13721	THROTTLE SHUTTER	1		
16	10	41354	SCREW, THROTTLE SHUTTER I	2		
17	13	26996	LOCKWASHER	2		
18	12	24676	WASHER	2		
19		13521	THROTTLE SHAFT	1		
20		13520	PIVOT, SHUTTER SHAFT	1		
21	16	98851	STUD	1		
22	12	29245	WASHER	2		
23	11	20361	NUT	1		
24	10	41355	SET SCREW	1		
25	10	41089	SCREW	1		
26	13	26995	LOCKWASHER	1		
27		13519	STOP, SHUTTER SHAFT	1		
28	10	76566	SCREW	3		
29	11	30968	NUT	1		
30	24	13938	SPRING, THROTTLE RETURN	1		
31	23	13720	BUSHING	1		
32		96718A 2	SENSOR ASSEMBLY	1		
33	25	45711	"O" RING	1		
34	10	57583	SCREW	3		
35	13	26995	LOCKWASHER	3		
36	12	20670	WASHER	3		
37		15175	FLAME ARRESTOR	1		
38	54	33683	CLAMP	1		
39		16435	ADAPTOR, THROTTLE POSITION	1		
40	10	76290	SCREW, ADAPTOR	2		
41	12	26995	LOCKWASHER, ADAPTOR SCRE	2		