



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		87114A19	EXHAUST MANIFOLD ASSEMBLY	2	
2	22	33198A 1	PLUG, EXHAUST MANIFOLD	AR	9
3	22	36382	PLUG, PIPE - EXHAUST MANIFOL	4	
4	27	33395	GASKET, EXHAUST MANIFOLD T	2	3
5	10	53728	SCREW, EXHAUST MANIFOLD	8	
6	12	20553	WASHER, EXHAUST MANIFOLD	8	
7	22	87238	DRAIN COCK, EXHAUST MANIFO	2	
8	22	36305	ELBOW, EXHAUST MANIFOLD	2	
9	27	87105	GASKET, ELBOW	2	3
10		44354A 3	EXHAUST ELBOW ASSEMBLY (7	2	
11	22	36382	PLUG, PIPE - EXHAUST ELBOW	2	
12	22	33198A 1	PLUG, EXHAUST ELBOW	2	
13	10	43749	SCREW, MANIFOLD	6	
13	10	44387	SCREW, MANIFOLD	2	
14		13515	BRACKET, E.F.I. CONTROL BOX	1	
15	10	49668	SCREW, BRACKET TO ELBOW	2	
16	13	26993	LOCKWASHER, BRACKET SCREW	2	
17		11350A 3	E.F.I. CONTROL BOX ASSI	1	
18		12234 1	MOUNT, RUBBER	3	
19	84	65999A10	WIRE ASSEMBLY	1	
20	12	21631	WASHER, RUBBER MOUNT	3	
21	11	56374	NUT, RUBBER MOUNT	3	