



| Parts List |       |          |                             |     |         |          |
|------------|-------|----------|-----------------------------|-----|---------|----------|
| Ref        | Class | Part     | Description                 | Qty | Comment | Footnote |
| 1          | 22    | 33821    | CONNECTOR, FUEL LINE        | 1   |         |          |
| 2          | 32    | 15937    | FUEL LINE, FILTER TO PUMP   | 1   |         |          |
| 3          | 22    | 14384    | CONNECTOR, FUEL LINE TO FUE | 1   |         |          |
| 4          | 12    | 14470    | WASHER, FUEL LINE CONNECT   | 1   |         |          |
| 5          |       | 14351    | FUEL PUMP                   | 1   |         |          |
| 6          | 12    | 20128    | WASHER, FUEL PUMP STUD      | 1   |         |          |
| 7          | 11    | 40063 3  | NUT, FUEL PUMP STUD (5 MM)  | 1   |         |          |
| 8          | 12    | 20670    | WASHER, FUEL PUMP STUD      | 1   |         |          |
| 9          | 11    | 40063 2  | NUT, FUEL PUMP STUD (4 MM)  | 1   |         |          |
| 10         |       | 15938    | BRACKET, FILTER AND FUEL PU | 1   |         |          |
| 11         | 10    | 42113    | SCREW, BRACKET              | 4   |         |          |
| 12         | 12    | 26168    | WASHER, BRACKET SCREW       | 4   |         |          |
| 13         | 23    | 90523    | SPACER, BRACKET SCREW       | 4   |         |          |
| 14         | 54    | 93384    | CLAMP, FUEL PUMP            | 2   |         |          |
| 15         | 12    | 22886    | WASHER, FUEL LINE CONNECT   | 1   |         |          |
| 16         | 22    | 14383    | CONNECTOR, FUEL LINE TO FUE | 1   |         |          |
| 17         | 32    | 15939A 1 | FUEL LINE (4')              | 1   |         |          |
| 18         | 22    | 14382A 1 | FUEL FITTING ASSEMBLY       | 1   |         |          |
| 19         | 22    | 32876    | NIPPLE                      | 1   |         |          |
| 20         | 22    | 52930    | TEE                         | 1   |         |          |
| 21         |       | 16516    | TANK VALVE                  | 1   |         |          |
| 22         | 87    | 14355    | SWITCH, OIL PRESSURE        | 1   |         |          |
| 23         | 22    | 14475    | NIPPLE                      | 1   |         |          |
| 24         |       | 13516 1  | FUEL RAIL                   | 2   |         |          |
| 25         |       | 13518 1  | SUPPORT, FUEL RAIL          | 4   |         |          |
| 26         | 10    | 13684    | SCREW, FUEL RAIL            | 8   |         |          |
| 27         | 12    | 46101    | WASHER, FUEL RAIL SCREW     | 8   |         |          |
| 28         | 22    | 33821    | CONNECTOR                   | 3   |         |          |
| 29         | 32    | 13601    | FUEL LINE                   | 1   |         |          |
| 30         |       | 12026    | REGULATOR, FUEL PRESSURE    | 1   |         |          |
| 31         |       | 12026    | NUT, FUEL PRESSURE REGULA   | 1   |         |          |
| 32         |       | 14302    | BRACKET, REGULATOR          | 1   |         |          |
| 33         | 32    | 14474    | FUEL LINE                   | 1   |         |          |
| 34         | 32    | 14473    | FUEL LINE                   | 1   |         |          |
| 35         | 22    | 14472    | FITTING (90 DEGREES)        | 1   |         |          |
| 36         | 22    | 36382    | PLUG                        | 1   |         |          |
| 37         |       | 89876A 3 | BASE, FUEL FILTER           | 1   |         |          |
| 38         | 22    | 73379    | PIPE PLUG, BASE             | 2   |         |          |
| 39         | 10    | 26065    | SCREW, BASE                 | 2   |         |          |
| 40         | 11    | 35814    | NUT, BASE SCREW             | 2   |         |          |
| 41         | 25    | 60484 1  | FUEL FILTER                 | 1   |         |          |