



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		87114A19	EXHAUST MANIFOLD ASSEMBLY	2		
2	22	33198A 1	PLUG, EXHAUST MANIFOLD	AR		
3	22	36382	PLUG, PIPE - EXHAUST MANIFOL	4		
4	27	33395	GASKET, EXHAUST MANIFOLD T	2		1
5	10	53728	SCREW, EXHAUST MANIFOLD	8		
6	12	20553	WASHER, EXHAUST MANIFOLD	8		
7	22	16951A 1	DRAIN COCK, EXHAUST MANIFO	2		
8	22	36305	ELBOW, EXHAUST MANIFOLD	2		
9	27	87105 1	GASKET, ELBOW	2		1
10		44354A 3	EXHAUST ELBOW ASSEMBLY (7	2		
11	22	36382	PLUG, PIPE - EXHAUST ELBOW	2		
12	22	33198A 1	PLUG, EXHAUST ELBOW	2		
13	10	43749	SCREW, MANIFOLD	6		
13	10	44387	SCREW, MANIFOLD	2		
14		13515	BRACKET, E.F.I. CONTROL BOX	1		
15	10	49668	SCREW, BRACKET TO ELBOW	3		
16	13	26992	LOCKWASHER, BRACKET SCREW	3		
17		11350A 8	E.F.I. CONTROL BOX ASSI	1		
18		12234 1	MOUNT, RUBBER	3		
19	84	65999A10	WIRE ASSEMBLY	1		
20	12	21631	WASHER, RUBBER MOUNT	3		
21	11	56374	NUT, RUBBERT MOUNT	3		