



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		16542	1 INTAKE MANIFOLD	1		
2	10	37612	SCREW, INTAKE MANIFOLD (1-1,	2		
2	10	26487	SCREW, INTAKE MANIFOLD (1-1,	6		
2	10	68101	SCREW, INTAKE MANIFOLD (1-3,	4		
3	12	45175	WASHER, INTAKE MANIFOLD SC	12		
4	22	36382A	1 FITTING ASSEMBLY	1		
5	32	66285	4 HOSE	2		
6	87	14172A	2 SENSOR ASSEMBLY	1		
7	16	72809	STUD	1		
8	23	21866	SPACER	1		
9	12	21631	WASHER	2		
10		20586	NUT	1		
11	22	46982	ELBOW (90 DEGREES)	1		
12		13712	PCV VALVE	1		
13	32	93315	12 HOSE	2		
14	54	53101	CLAMP	4		
15		97850	ELBOW, BREATHER (90 DEGREE	2		
16	25	52188	GROMMET	2		
17		13746	FUEL INJECTOR	8		
18	25	45711	"O" RING, FUEL INJECTOR	8		1
19	53	90916	"E" RING, FUEL INJECTOR	8		
20	84	13793A	4 WIRING HARNESS, INJECTORS	1		