



| Parts List | | | | | | |
|------------|-------|----------|------------------------------|-----|--------------------------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| 1 | | 48709 | BRACKET, MOUNTING (FRONT) | 2 | | |
| 2 | 10 | 37612 | SCREW, MOUNTING BRACKET C | 6 | | |
| 3 | 13 | 35048 | LOCKWASHER, MOUNTING BRA | 6 | | |
| 4 | 10 | 47654 | SCREW, CLAMP - ADJUSTING TF | 2 | | |
| 5 | 13 | 32993 | LOCKWASHER, CLAMP ADJUSTI | 2 | | |
| 6 | 54 | 47528 | CLAMP, ADJUSTING TRUNNION | 4 | | |
| 6 | 54 | 47528 | CLAMP, ADJUSTING TRUNNION | 4 | | |
| 7 | 11 | 29553 | NUT, CLAMP ADJUSTING TRUNN | 2 | | |
| 8 | | 47601A 2 | BRACKET ASSEMBLY, MOUNTIN | 2 | SERIAL 00000000-02536059 | |
| 9 | | 47656 | MOUNT, MOUNTING BRACKET | 4 | SERIAL 00000000-02536059 | |
| 10 | 12 | 48611 | WASHER, MOUNTING BRACKET | 4 | SERIAL 00000000-02536059 | |
| 11 | 10 | 47652 | SCREW, ADJUSTING TRUNNION | 2 | SERIAL 00000000-02536059 | |
| 8 | | 52139A 4 | BRACKET ASSEMBLY, MOUNTIN | 2 | SERIAL 02536060-09999999 | |
| 9 | | 52753 | MOUNT, MOUNTING BRACKET | 4 | SERIAL 02536060-09999999 | |
| 10 | 12 | 48611 | WASHER, MOUNTING BRACKET | 4 | SERIAL 02536060-09999999 | |
| 11 | 10 | 52156 | SCREW, ADJUSTING TRUNNION | 2 | SERIAL 02536060-09999999 | |
| 12 | 14 | 48467 | TAB WASHER, ADJUSTING TRUI | 2 | | |
| 13 | 11 | 47525 | NUT, JAM - ADJUSTING TRUNNII | 2 | | |
| 14 | 17 | 22116 | PIN, ROD - JAM NUT | 2 | | |
| 15 | | 47518 | TRUNNION, ADJUSTING - MOUN | 2 | | |
| 16 | | 47986 | BRACKET, MOUNTING - ENGINE | 2 | | |
| 17 | 10 | 48254 | SCREW, MOUNTING BRACKET A | 4 | | |
| 18 | 13 | 31848 | LOCKWASHER, MOUNTING BRA | 4 | | |