



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		47553	HOUSING, FLYWHEEL (SINGLE C	1,		
1A		47554	HOUSING, FLYWHEEL (DOUBLE	,1		
2	22	48873	EXTENDER, OUTLET HOSE TO C	,1		
3	22	48872	ELBOW, OUTLET HOSE (45)	,1		
4	32	48944	HOSE, OUTLET - OIL COOLER TC	,1		
5	22	48246	ELBOW, OUTLET HOSE TO CYLII	,1		
6	22	48871	ELBOW, INLET HOSE TO OIL COI	,1		
7	32	48946	HOSE, INLET - OIL COOLER TO C	,1		
8	22	48246	ELBOW, INLET HOSE TO CYLINC	,1		
9	22	48874	FITTING, REDUCER - INLET HOS	,1		
10	38	47520	SERIAL PLATE	1,1		
11	10	20314	SCREW, SERIAL PLATE ATTACH	4,4		
12		47542	COVER, FLYWHEEL HOUSING	1,1		
13	10	28635	SCREW, COVER TO HOUSING (5	4,4		
14	13	26992	LOCKWASHER, COVER SCREW	4,4		
15	23	47511	SLEEVE, CONNECTING - FLYWHL	2,2		
16	22	32802	PLUG, DRAIN - FLYWHEEL HOU	1,1		
17	10	26632	SCREW, FLYWHEEL HOUSING T	3,		
17	10	26632	SCREW, FLYWHEEL HOUSING T	,1		
18	10	45363	SCREW, FLYWHEEL HOUSING T	2,		
18	10	52708	SCREW, FLYWHEEL HOUSING T	2,		
19	12	33181	WASHER, SEALING - FLYWHEEL	2,		
19	12	33181	WASHER, SEALING - FLYWHEEL	,4		
20		47610	COOLER, OIL RIGHT SIDE	1,1		
21		47490	COVER, OIL COOLER RIGHT SIDI	1,1		
22	27	47495	GASKET, OIL COOLER COVER RI	1,1		
20		47611	COOLER, OIL LEFT SIDE	,1		
21		47541	COVER, OIL COOLER LEFT SIDE	,1		
22	27	47496	GASKET, OIL COOLER COVER LI	,1		
23	25	47632	O RING, SEALING - OIL COOLER	2,		
23	25	47632	O RING, SEALING - OIL COOLER	,4		
24	11	47521	NUT, JAM - OIL COOLER	2,		
24	11	47521	NUT, JAM - OIL COOLER	,4		
25	22	47917	ELECTRODE, OIL COOLER	1,		
25	22	47917	ELECTRODE, OIL COOLER	,2		
26	10	20362	SCREW, OIL COOLER COVER TO	6,		
26	10	20362	SCREW, OIL COOLER COVER TO	,12		
27	12	36533	WASHER, OIL COOLER COVER S	2,		
27	12	36533	WASHER, OIL COOLER COVER S	,4		
27	13	26421	LOCKWASHER, OIL COOLER COV	4,		
27	13	26421	LOCKWASHER, OIL COOLER COV	,8		